

ECi  
(248 Zone Control Communicator) **ECi**

---

---

Arrowhead  
Alarm Products Ltd

---

# Program Summary Guide

*Proudly Designed and Manufactured in New Zealand*

# SOFTWARE VERSION

This manual relates to ECi control panels with software version **V10.3.26** and above

## Special Programming Operating Procedures

### **Programming addresses that have 32 options (Areas, Outputs & Keypads)**

When in Program mode there are many program addresses (eg P3E) where there are 32 options that can be selected. When in these locations the selection is always a two digit number, eg at P3E you can select up to 32 areas, if you wanted to select areas 1, 5, 9, 10, & 15 the data entries would be 01, 05, 09, 10, 15.

If you wanted to select all 32 you can press and hold the "9" button for 2 seconds to turn on all 32 options, if you wanted to turn them all off you can press and hold the "0" button for 2 seconds to turn them all off.

### **Deleting User codes, Account Codes, Telephone Numbers, etc**

If a numeric entry such as user codes, monitoring account codes, telephone numbers, etc, needed to be deleted you can press and hold the <Control> button then press the <0> button (maintained for compatibility with the current ELITE S operation) or you can press and hold the <0> button for 3 seconds to delete the entry.

### **Programming LCD custom text**

All LCD text is stored in the control panel memory and transferred to all keypads so the panel remains the master database at all times. If user text is changed (eg User Name, Area Name, Output Name, etc) the new text is broadcast to every LCD keypad on the bus as soon as the enter button is pressed to save the changes so all keypads have the new text immediately. If a new LCD keypad is added to the system the panel broadcasts the CRC's for all of the text blocks so the keypads can compare their CRC with the panels. If there is a difference in the CRC's indicating that the LCD and panel text don't match a request is made by the keypad to download all text blocks where the CRC's don't match ensuring all keypads stay up to date with the panel. This task is carried out in the back ground and does not have to be initiated by the installer or end user.

### **Key-switch Programming**

The Key-switch function has now been moved to being a zone function. If any arm/disarm option is turned on at P120E the associated zone will now be a key-switch, eg P120E48E options 1 & 3 turned on would mean that zone 48 is now a key-switch that can arm and disarm the area/s assigned at P121E48E.

### **LCD Keypad Operational Mode**

The full LCD keypad will always show "Areas Armed" as soon as any area associated with the keypad is armed. If option 4 is off at P96E for the associated keypad the "Areas Armed" will show one area at a time on the bottom line of the display. The full Area name will be shown. The area names will cycle through showing all currently armed areas. An armed area could be fully armed or stay armed. If some areas associated with the keypad are not armed the "Ready LED" will still turn off when zones are unsealed but they will not be displayed while "Areas Armed" is on. To see any unsealed (not Ready) zones you can press the "Enter" button to switch to the zone display menu. After 10 seconds of no button presses the display will revert back to the "Areas Armed" display. Alternatively if the "Down Arrow" button is pressed while the display is showing "Areas Armed" the display will change from showing the individual area names to area numbers. Up to 7 two digit area numbers can be displayed on the bottom line. If there are more than 7 areas armed the display will cycle through 7 area numbers at a time repeating the cycle once it has shown all areas. By repeatedly pressing the "Down Arrow" the user can control what areas are displayed on the bottom line. If the "Down Arrow" is not pressed for 15 seconds the display will revert back to normal. If option 4 is on at P96E for the associated keypad the "Areas Armed" will show up to 7 area numbers on the bottom line and will cycle through the list if more than 7 areas are armed. If the "Down Arrow" button is pressed the user can control what areas are displayed on the bottom line. If the "Down Arrow" is not pressed for 15 seconds the display will revert back to normal.

# ECi BULK COPY FUNCTION

There are a number of program locations where selected program data can be copied to a range of similar program addresses. The list of these program locations is shown below. As an example if user 100 was set up as a template and users 101 to 200 were to all have the same program options, by entering in P17E 100E followed by 101E then 200E the panel will copy all of the programmed data for user 100 to users 101 to 200. This feature can be performed multiple times, eg user 250 could be set up as a template then it could be copied to users 251 to 300.

Bulk COPY a User to a range of Users

**P17E    Template User #E Start User #E End User #E    Bulk COPY a User to a range of USERS**

Bulk COPY an Output to a range of Outputs

**P30E    Template Output #E Start Output #E End Output #E    Bulk COPY an Output to a range of OUTPUTS**

Bulk COPY an Area to a range of Areas

**P70E    Template Area #E Start Area #E End Area #E    Bulk COPY an Area to a range of AREAS**

Bulk COPY a Keypad to a range of Keypads

**P97E    Template Keypad #E Start Keypad #E End Keypad #E    Bulk COPY a Keypad to a range of KEYPADS**

Bulk COPY a Zone to a range of Zones

**P118E    Template Zone #E Start Zone #E End Zone #E    Bulk COPY a Zone to a range of ZONES**

# ECi LCD TEXT PROGRAM SUMMARY GUIDE

There are a number of program locations where custom text names can be programmed. These custom text names are used by the LCD keypad when displaying area names when armed and also when viewing events in memory mode.

<b>P16E</b>	<b>1-2000E</b>	<b>Program LCD KP "User" Name Text</b>	Program LCD KP "User" Name
<b>P25E</b>	<b>14E</b>	<b>This location is where the LCD KP "Idle" Display Name can be Programmed.</b>	LCD KP "Idle" Display Name
<b>P31E</b>	<b>1-32E</b>	<b>Program LCD KP "Output" Name Text</b>	Program LCD KP "Output" Name
<b>P69E</b>	<b>1-32E</b>	<b>Program LCD KP "Area" Name Text</b>	Program LCD KP "Area" Name
<b>P100E</b>	<b>1-32E</b>	<b>Program LCD KP "Keypad" Name Text</b>	Program LCD KP "Keypad" Name
<b>P169E</b>	<b>1-64E</b>	<b>Program LCD KP "Zone" Name Text</b>	Program LCD KP "Zone" Name

## DTMF COMMAND CONTROL SEQUENCE

If DTMF Command Control has been enabled the operation is performed as follows.

Call the control panel.

When the panel answers it will play the message "Enter your code followed by the # key".

At that point enter in your DTMF Code (program location P63E for Area Arm/Disarm or P175E12E for Output control) followed by the # key on the phone.

### **DTMF Arming and Disarming**

If for example the DTMF code to remotely arm and disarm Area 1 (P63E1E) was 1234 and Area 1 was disarmed, when you enter the Area 1 DTMF code;

**1234 #** - (you will hear the message "Area 1 Disarmed")

If you then press the \* key it will change the state of Area 1, eg

\* - (you will hear the message "Area 1 Armed")

### **DTMF Output Control**

If for example the DTMF code to remotely control Outputs (P175E12E) was 9876 and you were controlling Output 1 (which was currently Off), when you enter the Output DTMF code followed by output 1 (01);

**9876 01 #** - (you will hear the message "Output 1 Off")

If you then press the \* key it will change the state of Output 1, eg

\* - (you will hear the message "Output 1 On")

### **Exiting DTMF Control Mode**

When all DTMF remote control functions are completed you can either hang up the phone and the control panel will hang up automatically in 15 seconds or you can press;

**00 #** - (you will hear "Goodbye") and the panel will hang up immediately.

# DISPLAY IP & MAC ADDRESS AT THE KEYPAD

When the panel is in normal mode (ie not in program mode) it is possible to display the currently assigned IP address for the panel and the MAC address. This feature is only available at the full LCD Keypad, it is not available on the ICON LCD keypad.

## **To view the MAC Address**

At the LCD keypad press and hold the <8> button for 4 seconds until the display shows the panels MAC address. To exit the display mode press the <ENTER> button.

## **To view the IP Address**

At the LCD keypad press and hold the <9> button for 4 seconds until the display shows the panels IP address. To exit the display mode press the <ENTER> button.

# Automatic Control of Doors

When there is a need to unlock a controlled door during the day and keep it unlocked, this can be achieved two ways. The first is to program a Time Zone to the output (P44E), the second is to program the area disarm indication to the output (P49E).

## **Unlock on a Time Zone**

Any of the 32 Time-zones can be assigned to outputs 1-32. This function can be used to unlock a controlled door so the door will remain unlocked while the T/Z is on and relock it when the T/Z is off allowing normal timed access control through the door when the T/Z is inactive. If a TZ has turned an Output ON the TZ will override any reset time programmed for the Output. A TZ can be linked to holidays (P174E option 1 Off) so that the TZ will not unlock the door when a holiday is active. The reset, pulse or chime timers can resume controlling the Output once the TZ has ended and the output is OFF. The CONTROL to Output function is the only operation that can override the Output while the TZ is active (see additional comment below).

## **Unlock when Disarmed**

Each Area can have a disarm indication assigned to an output to unlock a controlled door so the door will remain unlocked while the alarm is disarmed and relock it when the alarm is armed allowing normal timed access control through the door afterhours. This function allows a door to be unlocked only when the premises are occupied and relocked when the premises are vacated (ie the alarm is armed). If an Area Disarm has turned an Output ON this will override any reset time programmed for the Output. The reset, pulse or chime timers can resume controlling the Output once the Area is armed and the output is OFF. The CONTROL to Output function is the only operation that can override the Output while disarmed (see additional comment below).

## **<CONTROL> override of an unlocked door**

When an output is on because a TZ is active or the alarm is disarmed the output will stay on until the TZ is inactive or the alarm is armed.

At times there may be reasons why the door needs to be locked even if a TZ is active or the alarm is disarmed, (eg an employee is at work on a public holiday and the alarm is disarmed but they want the door to be locked).

Under these special conditions it is possible to program the output connected to the door so that it can be controlled using the <CONTROL> button at the keypad closest to the controlled door. At Program address P83E the output controlling the door can be assigned to a keypad close to the controlled door. By pressing the control button for 2 seconds (option 8 must be on at P96E to allow direct control of the output) the door control can be overridden. If the control button is pressed for another 2 seconds it will unlock the door again.

# ECi PROGRAM SUMMARY GUIDE

## +++++USERS+++++

### Programming User Codes

**P1E 1-2000E User Code 1-2000** - Default for User Code # 1 (P1E1E) = 123 Codes can be 1-6 or 4-6 digits.  
(where 1E = User Code #1 to 2000E = User Code #2000)

**NOTE:** The 2000 Users can be keypad Code, Radio or Access key Users. They can be mixed but the Maximum is 2000 Users.  
The User type MUST be set to "0" (P2E User# E) for a code to be entered at the above address.

### User Type (Code/Radio/Access Tag-Card)

**P2E 1-2000E User # 1-2000 Type -** (Default = 0)  
0 = Keypad Code User {PIN}  
1 = Radio User (Users 101-2000 only)  
2 = Access Tag/Card User  
3 = Both Code and Access Tag/Card User {Tag + PIN}  
4 = Either Code or Access Tag/Card User {Tag or PIN}

### User Area Assignment

**P3E 1-2000E User # 1-2000 Area -** (Default = 1)  
01-32 = Assigned to Area 1-32

### User Code Access Options

**P4E 1-2000E Users 1-2000 Access Options** (Default = 1,3,4)  
1 = Code can Arm Area  
2 = Code can arm Stay Mode  
3 = Code can Disarm Area  
4 = Code can disarm Stay Mode  
5 = Code is a Security Guard Code  
6 = Code will Arm Latchkey Mode  
7 = User can reset latched Egress Outputs  
8 = Can View Event Memory

### User Code Privileges

**P5E 1-2000E Users 1-2000 Privileges**  
(Default User 1 = 2,3,4,5,6,7,8)  
(Default User 2-2000 = All Off)  
1 = User can Change their Code  
2 = User can Change All Codes  
3 = User can Allow Access to Installer Mode/Edit all Codes  
4 = User can Change Telephone Numbers  
5 = User can Change the Clock  
6 = User can Change DTMF Command Codes  
7 = User can Learn New Radio Devices  
8 = Spare

### User Code Misc Options

**P6E 1-2000E Users 1-2000 Misc Opts**  
1 = User is excluded from Global trouble reset (P25E10E)

### Radio User Type

**P7E 101-2000E Radio User 101-2000 Type** (Default = 0)  
0 = General Pendant Type  
1 = Crow Freewave Pendant  
21 = Ness Pendant  
51 = Crow Shepherd (SH) Remote (Limit of 20)

### Radio User Privileges

**P8E 101-2000E Radio Users 101-2000 Privileges** (Default = 1)  
1 = Pendant Can Disarm at All Times  
2 = Pendant Causes Immediate Panic  
3 = Pendant Causes Delayed Panic ( 1.5 Sec)  
4 = Pendant only works during Entry Delay  
5 = This User is a Duress Code (Users 101-2000)  
6 = Spare  
7 = Spare  
8 = Spare

### Time Zone Assigned to a User

**P9E 1-2000E Time Zone to User # 1-2000** (Default = All Off)  
01 = User Controlled by Time Zone # 1  
02 = User Controlled by Time Zone # 2  
03 = User Controlled by Time Zone # 3  
04 = User Controlled by Time Zone # 4  
05 = User Controlled by Time Zone # 5  
06 = User Controlled by Time Zone # 6  
07 = User Controlled by Time Zone # 7  
08 = User Controlled by Time Zone # 8  
a  
32 = User Controlled by Time Zone # 32

### User Activates Dormant Time Zone

**P1032E 1-2000E User Activates Time Zone # 1-2000** (Default = All Off)  
01 = User Activates Time Zone # 1  
02 = User Activates Time Zone # 2  
03 = User Activates Time Zone # 3  
04 = User Activates Time Zone # 4  
05 = User Activates Time Zone # 5  
06 = User Activates Time Zone # 6  
07 = User Activates Time Zone # 7  
08 = User Activates Time Zone # 8  
a  
32 = User Activates Time Zone # 32

Access Group for User 1-2000

**P1033E 1-2000E Access Group for User # 1-2000**  
(Default = 0)

Value = Access group 1-32

User to Keypad Assignment

**P10E 1-2000E User # 1-2000 Keypad Assignment**  
(Default = All On)

- 01 = Can Operate at Keypad # 1
- 02 = Can Operate at Keypad # 2
- 03 = Can Operate at Keypad # 3
- 04 = Can Operate at Keypad # 4
- 05 = Can Operate at Keypad # 5
- 06 = Can Operate at Keypad # 6
- 07 = Can Operate at Keypad # 7
- 08 = Can Operate at Keypad # 8
- â
- 32 = Can Operate at Keypad # 32

Radio Pendant Panic Beeps to Keypad

**P11E 101-2000E Radio # 101-2000 Panic Beep to Keypad**  
(Default = All On)

- 01 = A Radio panic will Beep at Keypad # 1
- 02 = A Radio panic will Beep at Keypad # 2
- 03 = A Radio panic will Beep at Keypad # 3
- 04 = A Radio panic will Beep at Keypad # 4
- 05 = A Radio panic will Beep at Keypad # 5
- 06 = A Radio panic will Beep at Keypad # 6
- 07 = A Radio panic will Beep at Keypad # 7
- 08 = A Radio panic will Beep at Keypad # 8
- â
- 32 = A Radio panic will Beep at Keypad # 32

User can Turn an Output On

**P13E 1-2000E User # 1-2000 Can Turn On an Output**  
(Default = All Off)

- 01 = User Can Turn on Output # 1
- 02 = User Can Turn on Output # 2
- 03 = User Can Turn on Output # 3
- 04 = User Can Turn on Output # 4
- 05 = User Can Turn on Output # 5
- 06 = User Can Turn on Output # 6
- 07 = User Can Turn on Output # 7
- 08 = User Can Turn on Output # 8
- â
- 32 = User Can Turn on Output # 32

User can Turn an Output Off

**P14E 1-2000E User # 1-2000 Can Turn Off an Output**  
(Default = All Off)

- 01 = User Can Turn off Output # 1
- 02 = User Can Turn off Output # 2
- 03 = User Can Turn off Output # 3
- 04 = User Can Turn off Output # 4
- 05 = User Can Turn off Output # 5
- 06 = User Can Turn off Output # 6
- 07 = User Can Turn off Output # 7
- 08 = User Can Turn off Output # 8
- â
- 32 = User Can Turn off Output # 32

Radio Pendant Panic Alarm to an Output

**P15E 101-2000E Radio # 101-2000 Panic Alarm to an O/P**  
(Default = 1,2)

- 01 = Radio panic to Output # 1
- 02 = Radio panic to Output # 2
- 03 = Radio panic to Output # 3
- 04 = Radio panic to Output # 4
- 05 = Radio panic to Output # 5
- 06 = Radio panic to Output # 6
- 07 = Radio panic to Output # 7
- 08 = Radio panic to Output # 8
- â
- 32 = Radio panic to Output # 32

Program LCD KP "User" Name

**P16E 1-2000E Program LCD KP "User" Name Text**

Bulk COPY a User to a range of Users

**P17E Template User #E Start User #E End User #E Bulk COPY a User to a range of USERS**

Learn Radio Pendant Codes

**P18E 101-2000E Learn Radio Pendant Codes for Users 101-2000**  
(applies if the User Type, P2E, is set to 1)

Delete a Specific Radio Pendant Code

**P19E 101-2000E Delete a Specific Radio Pendant Code for Users 101-2000**  
(applies if the User Type, P2E, is set to 1)

Find Radio Pendant memory Location

**P20E ENTER Enter this address then operate the Radio Pendant to find its user #**  
(applies if the User Type, P2E, is set to 1). After P20E press enter to start the find process.

Learn Access Tag/Card Codes

**P21E 1-2000E Learn Access Tag/Card Codes for Users 1-2000**  
(applies if the User Type, P2E, is set to 2, 3 or 4)

## Delete a Specific Access Tag/Card Code

- P22E 1-2000E Delete a Specific Access Tag/Card Code for Users 1-2000**  
(applies if the User Type, P2E, is set to 2, 3 or 4)
- Find an Access Tag/Card memory Location
- P23E Enter this address then operate the Access Tag/Card to find its user #**  
(applies if the User Type, P2E, is set to 2, 3 or 4). After P23E press enter to start the find process.
- Manually enter in a Card/Tag Printed Number
- P24E 1-2000E Enter this address then type in the 10 digit printed card/tag number #**
- Code/Tag/Radio User Usage Count
- P1025E 1-2000E A value of 1-254 equals the number of times it can be used. 255 = always.**
- Code/Tag/Radio User Start Date
- P1026E 1-2000E DD:MM:YY The date a Code/Tag/Radio User will start to function.**
- Code/Tag/Radio User End Date
- P1027E 1-2000E DD:MM:YY The date a Code/Tag/Radio User will cease to function.**
- Code/Tag/Radio User Start Time
- P1028E 1-2000E HH:MM The time a Code/Tag/Radio User will start to function.**
- Code/Tag/Radio User End Time
- P1029E 1-2000E HH:MM The time a Code/Tag/Radio User will cease to function.**
- SH remote Unique ID Number
- P1031E 101-2000E Manually enter or read the SH remote 7 digit ID number.**
- SH remote Button 2 (LOCK) User #
- P1042E 101-2000E Assign Button 2 on a SH remote to a different User, 101-2000.**
- SH remote Button 3 (STAY-PA) User #
- P1043E 101-2000E Assign Button 3 on a SH remote to a different User, 101-2000.**
- SH remote Button 4 (\* -PA) User #
- P1044E 101-2000E Assign Button 4 on a SH remote to a different User, 101-2000.**  
(NOTE: If P1042/1043/1044 are all set to zero on the same user the button functions are as printed)

## +++++Miscellaneous Panel & Glock Settings+++++

- Installer Code
- P25E 1E Installer Code - ( Default = 000000)**
- Duress Digit
- P25E 2E Duress Digit - Value 1-9 (Default = 0 Duress Function Disabled)**
- Dial Report Delay
- P25E 3E Dial Report Delay - Value 0-255 seconds (Default = 0)**
- Radio Detector Supervised Timer
- P25E 4E Radio Detector Supervised Timer - 0-9999 Minutes (Default = 240 Minutes [4 Hours])**
- Two Trigger Timer
- P25E 5E Two Trigger Timer - Value 0-255 Seconds (Default = 60 Sec)**
- Mains Fail Reporting Delay
- P25E 6E Mains Fail Reporting Delay - Value 0-9999 Seconds (Default = 600 Sec)**
- Receiver Fail Delay
- P25E 7E Receiver Fail Delay - Value 0-9999 Seconds (Default = 0 Sec-Disabled)**
- Upload/Download Site Code Number
- P25E 8E Upload/Download Site Code Number - Up to 8 Characters (Default = None)**
- Temporary Output Disable
- P25E 9E Temporary Output Disable - Output 1-32**
- Miscellaneous Panel Options
- P25E 10E Misc. Panel Options (Default = 2,6)**
- Miscellaneous Options
- 1 = Panel Tamper is 2k2 EOL  
2 = Direct access to program mode for the installer code.  
3 = Disable Mains Fail Test  
4 = Globally reset trouble alarms  
5 = Cannot arm the alarm if Receiver fail mode is active  
6 = Enable iPSU AC and Battery Low monitoring  
7 = Cannot arm if the system battery is low  
8 = Installer Lockout
- Installer Options
- P25E 11E Installer Options (Default = All Off)**
- 1 = Installer MUST enter program mode via Client mode to reset confirmed alarms  
2 = Installer MUST enter program mode via Client mode to reset tamper alarms  
3 = Installer MUST enter program mode via Client mode to reset low battery alarms



- 4 = Installer **MUST** enter program mode via Client mode to reset supervisory alarms
- 5 = Cannot Arm if there is a keypad Fault
- 6 = Cannot Arm if there is a Telephone Line Failure or Comms Fault
- 7 = 10 Incorrect Code Attempts locks out the keypad for 90 Seconds
- 8 = User Codes Must be 4-6 digits long

## User Options

**P25E 12E User Options (NOTE: This Option can ONLY be accessed from Client Mode)**  
(Default = All Off)

**P25E 13E Misc. User Options**  
(Default = None)

- Miscellaneous User Options**
- 1 = Hide User Codes from Installer
  - 2 = Cancel Handover Zone Function in Stay Mode
  - 3 = Output Control from Keypad is Disabled when Armed
  - 4 = Keypad Codes are Disabled During Entry Delay
  - 5 = Keypad LED's and Backlight off on no activity
  - 6 = Use new multi-area arming method
  - 7 = Enable Keypad Tamper Switch Alarms
  - 8 = Spare

## LCD KP "Idle" Display Name

**P25E 14E This location is where the LCD KP "Idle" Display Name can be Programmed.**

## Webpage "Incorrect Login" Count

**P25E 15E 0-255. If this address is set to 0 there is no incorrect login count. If set from 1-255, that is the number of incorrect login attempts before the webpage access is locked out.**

## Webpage "Incorrect Login" Lockout Time

**P25E 16E 0-9999. If this address is set to 0 there is no lockout time if the programmed count at P25E15E is exceeded. If set from 1-9999, that is the time in seconds that all webpage access will be locked out for.**

## World Time Zone

**P25E 17E World Time Zone**

## Program Mode/Arming Options

**P25E 18E Prog/Arm Options**  
(Default = None)

- Program Mode/Arming Options**
- 1 = Can enter program mode when another area is armed
  - 2 = Can arm when a keypad in a different area is in program mode
  - 3 = Serial over IP Authentication Required
  - 8 = Hide extended information in the memory events

## Serial over IP User Name

**P25E 19E Serial over IP User Name (maximum 16 characters)**

## Serial over IP Password

**P25E 20E Serial over IP Password (maximum 16 characters)**

## Serial over IP User Timeout

**P25E 21E Serial over IP User Timeout (Default = 300, 10-600 seconds)**

## KP Bus Device Alarms

**P25E 22E KP Bus Device Alarms**  
(Default = None)

- KP Bus Device Alarm Options**
- 1 = Disable Zone Expander missing and tamper Alarms
  - 2 = Disable Output Expander missing and tamper Alarms
  - 3 = Disable Access board IF-2 missing and tamper Alarms

## LCD Keypad Language Selection

**P25E 23E LCD KP Languages**  
(NOTE: Use left/right arrow keys to select)

(Default = English)

## LCD Keypad language Selection

- 1 = English
- 2 = Turkish
- 3 = Romanian

## Setting Real Time Clock

**P26E 1E Real Time Hour/Minute - Value 0-2359**

**P26E 2E Real Time Day of Week - Value 1-7 (1=Sunday, 2=Monday ,etc)**

**P26E 3E Real Time Date/Month/Year - Value DDMMYY (eg 020904 = 2nd Sept 2004)**

**P26E 4E Daylight Saving is Active** (If LED #1 is On, Daylight Saving is currently active) Turn this bit ON if you are in Daylight Saving Time when the panel is installed.

**NOTE: If option 3 at P201E4E is turned on (panel clock synced to the internet time) the above time and date settings cannot be altered.**

## Daylight Saving settings

**P27E 1E Daylight Saving Start Sunday - Value 0-5 - Default = 5 (0 = DLS disabled, 5 = last Sunday of Month)**

**2E Daylight Saving End Sunday - Value 0-5 - Default = 1 (0 = DLS disabled, 5 = last Sunday of Month)**

**P28E 1E Daylight Saving Start Month - Value 1-12 - Default = 9 (0 = DLS disabled)**

**2E Daylight Saving End Month - Value 1-12 - Default = 4 (0 = DLS disabled)**

**P29E 1E Daylight Saving Start Hour - Value 0-23 - Default = 2**

**2E Daylight Saving End Hour - Value 0-23 - Default = 3**

## +++++Outputs+++++

			Bulk COPY an Output to a range of Outputs
<b>P30E</b>	<b>Template O/P #E</b>	<b>Start O/P #E End O/P #E</b>	<b>Bulk COPY an Output to a range of OUTPUTS</b>
<b>P31E</b>	<b>1-32E</b>	<b>Program LCD KP "Output" Name Text</b>	<b>Program LCD KP "Output" Name</b>
<b>P33E</b>	<b>1-2E</b>	<b>The Volume of O/P 1 &amp; 2 when the alarm is disarmed can be set to a value of 1-8</b>	<b>Program Output Volume when Disarmed</b>
<b>P3101E</b>	<b>1-32E</b>	<b>Output #1 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7</b>	<b>Program Access Groups</b>
<b>P3102E</b>	<b>1-32E</b>	<b>Output #2 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7</b>	
<b>P3103E</b>	<b>1-32E</b>	<b>Output #3 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7</b>	
<b>P3104E</b>	<b>1-32E</b>	<b>Output #4 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7</b>	
<b>P3105E</b>	<b>1-32E</b>	<b>Output #5 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7</b>	
<b>P3106E</b>	<b>1-32E</b>	<b>Output #6 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7</b>	
<b>P3107E</b>	<b>1-32E</b>	<b>Output #7 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7</b>	
<b>P3108E</b>	<b>1-32E</b>	<b>Output #8 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7</b>	
<b>P3109E</b>	<b>1-32E</b>	<b>Output #9 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7</b>	
<b>P3110E</b>	<b>1-32E</b>	<b>Output #10 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7</b>	
<b>P3111E</b>	<b>1-32E</b>	<b>Output #11 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7</b>	
<b>P3112E</b>	<b>1-32E</b>	<b>Output #12 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7</b>	
<b>P3113E</b>	<b>1-32E</b>	<b>Output #13 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7</b>	
<b>P3114E</b>	<b>1-32E</b>	<b>Output #14 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7</b>	
<b>P3115E</b>	<b>1-32E</b>	<b>Output #15 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7</b>	
<b>P3116E</b>	<b>1-32E</b>	<b>Output #16 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7</b>	
<b>P3117E</b>	<b>1-32E</b>	<b>Output #17 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7</b>	
<b>P3118E</b>	<b>1-32E</b>	<b>Output #18 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7</b>	
<b>P3119E</b>	<b>1-32E</b>	<b>Output #19 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7</b>	
<b>P3120E</b>	<b>1-32E</b>	<b>Output #20 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7</b>	
<b>P3121E</b>	<b>1-32E</b>	<b>Output #21 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7</b>	
<b>P3122E</b>	<b>1-32E</b>	<b>Output #22 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7</b>	
<b>P3123E</b>	<b>1-32E</b>	<b>Output #23 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7</b>	
<b>P3124E</b>	<b>1-32E</b>	<b>Output #24 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7</b>	
<b>P3125E</b>	<b>1-32E</b>	<b>Output #25 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7</b>	
<b>P3126E</b>	<b>1-32E</b>	<b>Output #26 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7</b>	
<b>P3127E</b>	<b>1-32E</b>	<b>Output #27 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7</b>	
<b>P3128E</b>	<b>1-32E</b>	<b>Output #28 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7</b>	
<b>P3129E</b>	<b>1-32E</b>	<b>Output #29 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7</b>	
<b>P3130E</b>	<b>1-32E</b>	<b>Output #30 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7</b>	
<b>P3131E</b>	<b>1-32E</b>	<b>Output #31 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7</b>	
<b>P3132E</b>	<b>1-32E</b>	<b>Output #32 Access Group 1-32 assigned Schedule 1-32, 0=NONE, 33 = 24/7</b>	
<b>P34E</b>	<b>1-32E</b>	<b>Options "A" for Outputs 1-32</b> (Default = All Off)	<b>Programming Output Options "A"</b>
		1 = Invert Output	
		2 = Flash Output	
		3 = Single Pulse to Output	
		4 = Lockout Output	
		5 = DTMF Remote Control can operate Output	
		6 = User Can operate this Output	
		7 = "Control" button Can Operate Output	
		8 = Chime Alarms will Flash this Output (linked to Pulse Timer)	
<b>P35E</b>	<b>1-32E</b>	<b>Options "B" for Outputs 1-32</b> (Default O/P's 1&2 = 7) (Default O/P's 3-8 = All Off)	<b>Programming Output Options "B"</b>
		1 = Mains Fail to Output (Operates when P25E6E time expires)	
		2 = Fuse Failure to Output	
		3 = Battery Low to output	
		4 = Telephone Line Failure to Output	
		5 = Supervised Radio Signal Failure	
		6 = Sensor-Watch Alarm	
		7 = System Tamper to Output	
		8 = Receiver Fail	
<b>P36E</b>	<b>1-32E</b>	<b>Options "C" for Outputs 1-32</b> (Default = All Off)	<b>Programming Output Options "C"</b>
		1 = Walk Test Pulse to Output	
		2 = Pulse Output every 5 seconds when Disarmed	
		3 = Pulse Output on Kiss-off Following Arming	
		4 = Pulse Output on Kiss-off Following a Zone Alarm	
		5 = Output Disabled when P25E3E timer is running	
		6 = Output indicates In-coming phone call.	
		7 = Play Doorbell tone on a Chime zone trigger	
		8 = IP Fail (Timed)	

## Programming Output Options "D"

- P37E 1-32E Options "D" for Outputs 1-32** (Default = All Off)
- 1 = Siren Driver to Output (requires a horn speaker, outputs 1&2)
  - 2 = Output Chime timer is in minutes (off for 1/10th sec)
  - 3 = Output 'silenced' for 10 seconds on key-press if alarm
  - 4 = Turn Output OFF during Two Way Voice Mode
  - 5 = Spare
  - 6 = Pulse output when exit delay to Output (P65E) is running
  - 7 = Output follows "Global Fire Egress Zone"
  - 8 = Monitored Output (can tell if siren cable is cut, outputs 1&2 only)
- Output ON Delay Time
- P38E 1-32E Output 1-32 ON Delay Time** - 0-9999 Seconds (Default = 0 Sec)
- Output Pulse Time
- P39E 1-32E Output 1-32 Pulse Time** - 0-255;1/10th Sec increments (Default =2 which is 0.2 sec)
- Output Reset Time
- P40E 1-32E Output 1-32 Reset Time** - 0-65535 Seconds (Default = 300 Sec)
- Output Chime Mode Time
- P41E 1-32E Output 1-32 Chime Timer** - 0-9999;1/10th Sec increments (Default =10 which is 1 sec)
- IP Fail Re-Trigger Timer
- P42E 1-32E IP Fail Re-Trigger Timer** - 0-9999 Seconds
- Un-Map an Output
- P43E 1-32E Un-map Outputs 1-32 (remove ALL Defaults from an Output)**
- Assigning a Time-zone to an Output
- P44E 1-32E Time-zones that will control Outputs 1-32** - Value = Time-zone 01-32 (Default = All Off)
- (NOTE: If a TZ has turned an Output ON the TZ will override any reset time programmed for the Output. The reset, pulse or chime timers can resume controlling the Output once the TZ has ended and the output is OFF. The CONTROL to Output function is the only operation that can override the Output while the TZ is active.)*

**NOTE: Shepherd Siren and Output devices can ONLY be assigned to outputs 1-16 as shown below.**

- SH OUTPUT Device Type
- P3050E 1-16E SH Output Device Type** (Default = )
- 70 = SH Siren
  - 89 = SH IO 2X2
- SH Device Unique ID Number
- P3051E 1-16E Manually enter or read the Shepherd (SH) Output device 7 digit ID number.**
- SH IO 2X2 Output Number
- P3052E 1-16E SH IO 2X2 Output Number** (Default = )
- 1 or 2
- SH SIREN Options
- P3053E 1-16E SH Siren Options** (Default = )
- 1 = LED Enabled
  - 2 = Local DIP Switches enabled
- SH SIREN Speaker Volume
- P3054E 1-16E SH Siren Speaker Volume** (Default = )
- 0 = Quiet
  - 1 = Medium
  - 2 = Loud
  - 3 = Loudest

### +++++Areas+++++

- Area 1-32 Options A
- P45E 1-32E Area 1-32 Options A** (Default = All Off)
- 1 = Arm Button Required Before Code to Set
  - 2 = Stay Button Required Before Code to Set Stay Mode
  - 3 = Code required to Set
  - 4 = Code Required to Bypass Zones
  - 5 = Spare
  - 6 = Send Arm at the end of the Exit Delay
  - 7 = Can Arm only if All Zones are Sealed (Ready)
  - 8 = Can Arm Stay Mode only if All Zones are Sealed (Ready)
- Area 1-32 Options B
- P46E 1-32E Area 1-32 Options B** (Default = All Off)
- 1 = Near and Confirmed Alarm reporting for All zones in this Area (CID only)
  - 2 = Area will arm at end of time-zone
  - 3 = Area will disarm at beginning of time-zone
  - 4 = Assign Chirps to Access tags
  - 5 = Spare
  - 6 = Inhibit Arming if zone unsealed while Exit Delay is Active.
  - 7 = Cannot Arm if Zone Unsealed at end of Exit Delay
  - 8 = Arm on no Activity
- Area 1-32 Arm Indication to Output
- P47E 1-32E Area 1-32 Arm Indication to Output** - Value 01-32 (for Outputs 1-32) (Default = All Off)

- Area 1-32 Stay Arm Indication to Output
- P48E 1-32E Area 1-32 Stay Arm Indication to Output** - Value 01-32 (for Outputs 1-32)  
(Default = All Off)
- Area 1-32 Disarm Indication to Output
- P49E 1-32E Area 1-32 Disarm Indication to Output** - Value 01-32 (for Outputs 1-32)  
(Default = All Off)
- (NOTE: If an Area Disarm has turned an Output ON this will override any reset time programmed for the Output. The reset, pulse or chime timers can resume controlling the Output once the Area is armed and the output is OFF. The CONTROL to Output function is the only operation that can override the Output while disarmed.)*
- Area 1-32 Pendant (or Access Tag) Arm Chirp to Output
- P50E 1-32E Area 1-32 Arm Chirp to Output** - Value 01-32 (for Outputs 1-32)  
(Default = All Off) **(One chirp to the output for arm)**
- Area 1-32 Pendant (or Access Tag) Stay Arm Chirp to Output
- P51E 1-32E Area 1-32 Stay Arm Chirp to Output** - Value 01-32 (for Outputs 1-32)  
(Default = All Off) **(One chirp to the output for stay arm)**
- Area 1-32 Pendant (or Access Tag) Disarm Chirp to Output
- P52E 1-32E Area 1-32 Disarm Chirp to Output** - Value 01-32 (for Outputs 1-32)  
(Default = All Off) **(Two chirps to the output for disarm)**
- Area 1-32 Pendant Stay (or Access Tag) Disarm Chirp to Output
- P53E 1-32E Area 1-32 Stay Disarm Chirp to Output** - Value 01-32 (for Outputs 1-32)  
(Default = All Off) **(Two chirps to the output for disarm)**
- Area 1-32 Arm Pulse to Output
- P54E 1-32E Area 1-32 Arm Pulse to Output** - Value 01-32 (for Outputs 1-32)  
(Default = All Off)
- Area 1-32 Stay Arm Pulse to Output
- P55E 1-32E Area 1-32 Stay Arm Pulse to Output** - Value 01-32 (for Outputs 1-32)  
(Default = All Off)
- Area 1-32 Disarm Pulse to Output
- P56E 1-32E Area 1-32 Disarm Pulse to Output** - Value 01-32 (for Outputs 1-32)  
(Default = All Off)
- Area 1-32 Stay Disarm Pulse to Output
- P57E 1-32E Area 1-32 Stay Disarm Pulse to Output** - Value 01-32 (for Outputs 1-32)  
(Default = All Off)
- Area 1-32 Armed Mode Exit Delay Beeps to Keypad
- P58E 1-32E Area 1-32 Armed Exit Delay Beeps to Keypad** - Value 01-32 (for Keypads 1-32)  
(Default, Area 1 = All On, Areas 2-32 = All Off)
- Area 1-32 Stay Mode Exit Delay Beeps to Keypad
- P59E 1-32E Area 1-32 Stay Exit Delay Beeps to Keypad** - Value 01-32 (for Keypads 1-32)  
(Default Area 1 = All On, Areas 2-32 = All Off)
- Area 1-32 Armed Exit Delay Time
- P60E 1-32E Area 1-32 Exit Delay Time** - Value 0-255 seconds  
(Default = 30 Seconds for all Areas)
- Area 1-32 Stay Armed Exit Delay Time
- P61E 1-32E Area 1-32 Stay Exit Delay Time** - Value 0-255 seconds  
(Default = 30 Seconds for all Areas)
- Area 1-32 Monitoring Account Code Number
- P62E 1-32E Area 1-32 Account Code** - Value 0000-FFFF  
(Default = 0000 for all Areas)
- Area 1-32 Remote "Command Control" Code Number
- P63E 1-32E Area 1-32 Command Control code** - Value 1-4 digit code (1-9999)  
(Default = No code for all Areas)
- Start Message Number for Areas 1-32 "Command Control"
- P64E 1-32E Reserved for future use.**
- Area 1-32 Armed Mode Exit Delay to Output
- P65E 1-32E Area 1-32 Armed Exit Delay to Output** - Value 01-32 (for Outputs 1-32)  
(Default = All Off)
- Area 1-32 Stay Mode Exit Delay to Output
- P66E 1-32E Area 1-32 Stay Exit Delay to Output** - Value 01-32 (for Outputs 1-32)  
(Default = All Off)
- Area 1-32 Delinquency Delay
- P67E 1-32E Area 1-32 Delinquency Delay** - value 0-99 Days, (0 = Off)  
(Default = 0 for all Areas)

Area 1-32 Auto Arm/Disarm Time-zones

- P68E 1-32E Area 1-32 Auto Arm/Disarm Time-zones** - Value 01-32 (for Time-zones 1-32)  
(Default = All Off)
- P69E 1-32E Program LCD KP "Area" Name Text** Program LCD KP "Area" Name
- P70E Template Area #E Start Area #E End Area #E Bulk COPY an Area to a range of AREAS** Bulk COPY an Area to a range of Areas  
Area 1-32 Zone Activity Timer
- P4071E 1-32E Area 1-32 Zone Activity Timer** - Value 0-255 Minutes  
(Default = 0)
- P4072E 1-32E Area 1-32 Arming Pre-alert Timer** - Value 0-255 Seconds  
(Default = 0)
- P4073E 1-32E Area 1-32 Disarm Delay Timer** - Value 0-9999 Seconds  
(Default = 0)
- P4074E 1-32E Area "In Alarm" Disarm Delay Timer** - Value 0-9999 Seconds  
(Default = 0)
- P4075E 1-32E This is a display only address that shows all Zones associated with the selected Area** Zones Associated with Areas 1-32  
Active Areas
- P4076E 1E This is a display only address that shows all Areas with Zones assigned to them**

+++++Keypads+++++
- P71E 1-32E Keypads Assigned To Areas** 01-32 = Areas 1-32  
(Default = 1,2)
- P72E 1-32E Keypad Button Options** 1 = <CHIME> Button Enabled  
(Default = All 1,2) 2 = <BYPASS> Button Enabled  
3 = Code or Tag can ARM only at this keypad  
4 = Code or Tag can STAY ARM only at this keypad  
(NOTE: Options 5, 6 & 7 create a separate alarm for every area assigned to the keypad at P71E. To clear all alarms the User MUST have the same areas set at P3E) 5 = <CONTROL> + <CHIME> Panic Alarm Enabled  
6 = <A> + <B> Fire Alarm Enabled  
7 = <B> + <CHIME> Medical Alarm Enabled  
8 = Stay Armed Beep to Keypad
- P5070E 1-32E Keypad Options C** 1 = Enable Away Disarm at Keypad  
(Default = All 1,2) 2 = Enable Stay Disarm at Keypad
- P73E 1-32E Keypad Beep Options** 1 = Mains Fail Beeps Keypad Buzzer  
(Default = 5) 2 = Fuse Failure Beeps Keypad Buzzer  
3 = Battery Low Beeps Keypad Buzzer  
4 = Telephone Line Failure Beeps Keypad Buzzer  
5 = System Tamper Alarm Beeps Keypad Buzzer  
6 = Receiver Fail Beeps Keypad Buzzer  
7 = Turn Off Keypad LED's and Backlighting when Armed  
8 = Turn Off LCD & Keypad & Backlighting on Mains Failure
- P74E 1-32E Keypad "ARM" Button Area** 01-32 = "ARM" Button assigned to Area 1-32  
(Default = 1)
- P75E 1-32E Keypad "ARM" Button Opts.** 1 = "ARM" Button can Arm  
(Default = 1,7) 2 = "ARM" Button can Stay Mode Arm  
3 = "ARM" Button can Disarm at All Times  
4 = "ARM" Button can Disarm Stay Mode at All Times  
5 = "ARM" Button can Reset Alarms  
6 = "ARM" Button can Arm Latchkey Mode  
7 = "ARM" Button can Disarm During Exit Delay  
8 = "ARM" Button can Disarm Stay Mode During Exit Delay
- P76E 1-32E Keypad "STAY" Button Area** 01-32 = "STAY" Button assigned to Area 1-32  
(Default = 1)
- P77E 1-32E Keypad "STAY" Button Opts.** 1 = "STAY" Button can Arm  
(Default K/P 1,2,3,4,6,7,8 = 2,8) 2 = "STAY" Button can Stay Mode Arm  
(Default K/P 5 = 2,4) 3 = "STAY" Button can Disarm at All Times  
4 = "STAY" Button can Disarm Stay Mode at All Times

- 5 = "STAY" Button can Reset Alarms
- 6 = "STAY" Button can Arm Latchkey Mode
- 7 = "STAY" Button can Disarm During Exit Delay
- 8 = "STAY" Button can Disarm Stay Mode During Exit Delay

### Keypad "A" Button Area Assignment

**P78E 1-32E Keypad "A" Button Area** (Default = 1) 01-32 = "A" Button assigned to Area 1-32

### Keypad "A" Button Area Options

**P79E 1-32E Keypad "A" Button Opts.** (Default = 1,7)

- 1 = "A" Button can Arm
- 2 = "A" Button can Stay Mode Arm
- 3 = "A" Button can Disarm at All Times
- 4 = "A" Button can Disarm Stay Mode at All Times
- 5 = "A" Button can Reset Alarms
- 6 = "A" Button can Arm Latchkey Mode
- 7 = "A" Button can Disarm During Exit Delay
- 8 = "A" Button can Disarm Stay Mode During Exit Delay

### Keypad "B" Button Area Assignment

**P80E 1-32E Keypad "B" Button Area** (Default = 2) 01-32 = "B" Button assigned to Area 1-32

### Keypad "B" Button Area Options

**P81E 1-32E Keypad "B" Button Opts.** (Default = All Off)

- 1 = "B" Button can Arm
- 2 = "B" Button can Stay Mode Arm
- 3 = "B" Button can Disarm at All Times
- 4 = "B" Button can Disarm Stay Mode at All Times
- 5 = "B" Button can Reset Alarms
- 6 = "B" Button can Arm Latchkey Mode
- 7 = "B" Button can Disarm During Exit Delay
- 8 = "B" Button can Disarm Stay Mode During Exit Delay

### Keypad to Output Mask (for Access Control)

**P82E 1-32E Keypad to Output Mask** (Default = All Off) 01-32 = The Keypad is linked to Output # 1-32

### "Control" Button to Output Mask (for Access Control)

**P83E 1-32E Keypad "Control" Button to Output Mask** (Default = All Off) 01-32 = The Keypad "Control" Button is linked to Output # 1-32

### "Control" + "Chime" Panic Alarm to Outputs

**P84E 1-32E Keypad "Control" + "Chime" Panic Alarm to Outputs** (Default = 1,2) 01-32 = The Keypad "Control" + "Chime" Panic Alarm will turn on Output # 1-32

### "A" + "B" Fire Alarm to Outputs

**P85E 1-32E Keypad "A" + "B" Fire Alarm to Outputs** (Default = 1,2) 01-32 = The Keypad "A" + "B" Fire Alarm will turn on Output # 1-32

### "B" + "Chime" Medical Alarm to Outputs

**P86E 1-32E Keypad "B" + "Chime" Medical Alarm to Outputs** (Default = 1,2) 01-32 = The Keypad "B" + "Chime" Medical Alarm will turn on Output # 1-32

### "Duress" Alarm to Outputs

**P87E 1-32E Keypad "Duress" Alarm to Outputs** (Default = All Off) 01-32 = The Keypad "Duress" Alarm will turn on Output # 1-32

### Keypad "Tamper Switch" Alarm to Outputs

**P88E 1-32E Keypad "Tamper Switch" Alarm to Outputs** (Default = All Off) 01-32 = The Keypad "Tamper Switch" Alarm will turn on Output # 1-32

### Keypad "Wrong Code" Alarm to Outputs

**P89E 1-32E Keypad "Wrong Code" Alarm to Outputs** (Default = All Off) 01-32 = The Keypad "Wrong Code" Alarm will turn on Output # 1-32

### Manually Operated Panic Alarm Beeps to Keypads

**P90E 1-32E Panic Alarm Beeps to Keypads** (Default = All On) 01-32 = A Panic Alarm at the selected keypad will Beep KP # 1-32

### Manually Operated Fire Alarm Beeps to Keypads

**P91E 1-32E Fire Alarm Beeps to Keypads** (Default = All On) 01-32 = A Fire Alarm at the selected keypad will Beep KP # 1-32

### Manually Operated Medical Alarm Beeps to Keypads

**P92E 1-32E Medical Alarm Beeps to Keypads** (Default = All On) 01-32 = A Medical Alarm at the selected keypad will Beep KP # 1-32

### Wrong Code or Keypad Tamper Switch Alarm Beeps to Keypads

**P93E 1-32E Wrong Code or Keypad Tamper Switch Alarm Beeps to Keypads** (Default = All On) 01-32 = Wrong Code or KP Tamper at Keypad 1-32 will Beep KP # 1-32

### Chime Alarm Beep Time at a Keypad

**P94E 1-32E The Time the Chime Alarm will sound at Each Keypad** - Value = 0-255 1/10th sec (Default = 20 which is 2 Seconds)

- P95E 1-32E LCD Keypad Back-light Setting** 0-100 = LCD B/L value 0-100%  
LCD Keypad Back-light settings
- P96E 1-32E Full LCD Keypad Display Options** (Default = All Off)  
Full LCD Keypad Display Options  
1 = 2 x 20 Display Mode (On=AAP Logo Display)  
2 = Spare  
3 = Show LCD System name (ON=Show KP Name, 1 =OFF)  
4 = Display Armed Areas as numbers  
5 = Spare  
6 = Allow CONTROL of Outputs when Armed  
7 = Double badge to ARM keypad  
8 = Control button operates assigned outputs directly
- P97E Template KP #E Start KP #E End KP #E Bulk COPY a Keypad to a range of KEYPADS**  
Bulk COPY a Keypad to a range of Keypads
- P98E 1-32E Proximity Reader LED to Output Mapping** (Default = None) 01-32 = Proximity Reader 1-32 LED will follow the state of Output # 1-32  
Proximity Reader LED to Output Mapping
- P100E 1-32E Program LCD KP "Keypad" Name Text**  
Program LCD KP "Keypad" Name
- +++++ZONES+++++**
- P118E Template Zone #E Start Zone #E End Zone #E Bulk COPY a Zone to a range of ZONES**  
Bulk COPY a Zone to a range of Zones
- P119E 1E Global EOL Zone Options** (Default = 3) 0 = If set to 0 allows P125E to set individual values from 1-13  
Global EOL Zone Options  
1 = 1k  
2 = 1k5  
3 = 2k2  
4 = 3k3  
5 = 3k9  
6 = 4k7  
7 = 5k6  
8 = 6k8  
9 = 10k  
10 = 12k  
11 = 22k  
12 = 2k2 / 4k7 (Single Zone with tamper, Series combination)  
13 = 3k3 / 6k8 (Single Zone with tamper, Series combination)  
14 = 2k2 / 4k7 / 8k2 (Zone doubling with tamper, Series combination)  
15 = 4k7 / 8k2 (Zone doubling no tamper, Series combination)  
16 = 4k7 / 8k2 (Zone doubling no tamper, Parallel combination)
- P120E 1-248E Zone Key-switch Operational Options** (Default = All Off)  
Zone Key-switch Operational Options  
(NOTE: K/S operation linked to Users 1-64 settings P1025E - P1029E, see full manual for details)  
1 = K/S can Arm Area  
2 = K/S can arm Stay Mode  
3 = K/S can Disarm Area  
4 = K/S can disarm Stay Mode  
5 = K/S has Security Guard Options  
6 = K/S will Arm Latchkey Mode  
7 = Key-switch is N/O (If turned off the K/S is N/C)  
8 = Key-switch is Momentary (If turned off the K/S is Latching)
- P121E 1-248E Assigning Zones to Areas 1-32** (Default = 1)  
Assigning Zones to Areas 1-32  
01-32 = Assigned to Area 1-32
- P122E 1-248E Programming Zone Options A** (Default Zone 1-4 = 1,6,7,8) (Default Zone 5-8 = 1,7,8) (Default Zone 9-16 = 7,8)  
Programming Zone Options A  
1 = Zone is Active  
2 = Zone is N/O (Off = N/C)  
3 = Not an Exit Delay Zone  
4 = Keypad Zone  
5 = Zone is a Radio Zone  
6 = Zone is a Stay Mode Zone  
7 = Zone can be Manually Bypassed  
8 = Zone can be Auto-Bypassed
- P123E 1-248E Programming Zone Options B** (Default = All Off)  
Programming Zone Options B  
1 = Zone is a Handover Zone  
2 = Zone is a Two Trigger Zone  
3 = Zone is a 24 Hour Zone  
4 = Auto-reset Zone  
5 = Zone is a 24 Hour Fire Zone  
6 = Zone is shared (Off = not shared)  
7 = Zone is a Chime Zone  
8 = Zone is a Permanent Chime Zone

## Programming Zone Options C

**P124E 1-248E Programming Zone Options C**  
(Default = 2)

- 1 = Can Arm if Zone is not Ready
- 2 = Will Send Multiple Reports via Dialler
- 3 = Sensor-Watch Zone
- 4 = Zone is on Soak Test
- 5 = Report using the highest assigned Area
- 6 = Zone will Not Report 24 hour Alarms via Dialler
- 7 = Pulse Output on Kiss-off Following an alarm
- 8 = Exit Terminator

## Programming Zone Options D

**P6133E 1-248E Programming Zone Options D**  
(Default = All Off)

- 1 = Zone is Excluded from Activity monitoring
- 2 = Zone will hold off Arming until Sealed
- 3 = "Security Interlock" zone

## Programming Zone EOL (End-of-line) Options

**P125E 1-248E Programming Zone EOL Options**  
(Default = 3)  
(NOTE: P119E MUST be set to 0 for P125E to work)

- 0 = Short Circuit
- 1 = 1k
- 2 = 1k5
- 3 = 2k2
- 4 = 3k3
- 5 = 3k9
- 6 = 4k7
- 7 = 5k6
- 8 = 6k8
- 9 = 10k
- 10 = 12k
- 11 = 22k
- 12 = 2k2 / 4k7 (Single Zone with tamper)
- 13 = 3k3 / 6k8 (Single Zone with tamper)

## Programming Zone Response

**P126E 1-248E Programming Zone Response**  
(Default = 9)

- 1 to 8 Vibration mode  
**(Zone EOL-P125E, for Vibration Mode MUST be type 3 only)**
- 1 = highest and 8 is lowest sensitivity level.
- 9 to 26 Normal zone mode  
Response time = approx 200ms -1sec

## Programming the Radio Zone Detector Type

**P127E 1-248E Programming the Radio Zone Type from the List** - Value = 0-89  
(Default = 4)

- 0 = Generic
- 3 = Freewave with checksum (supervised signal active)
- 4 = Freewave with checksum (non-supervised)
- 49 = SH PIR
- 50 = SH MAG (Reed Switch)
- 51 = SH Remote
- 52 = SH Smoke
- 54 = SH Glassbreak
- 55 = SH PIR-CAM
- 57 = SH MAG/SHOCK
- 89 = SH IO 2X2

## Armed Zone Alarms to Outputs

**P128E 1-248E Armed Zone Alarms to Output**  
(Default = 1,2) 01-32 = A Zone Alarm will Turn On Output # 1-32

## Armed Stay Mode Zone Alarms to Outputs

**P129E 1-248E Armed Stay Mode Zone Alarms to Output**  
(Default = 2) 01-32 = A Stay Mode Zone Alarm will Turn On Output # 1-32

## 24 Hour Zone Alarms to Outputs

**P130E 1-248E 24 Hour Zone Alarms to Output**  
(Default = All Off) 01-32 = A 24 Hour Zone Alarm will Turn On Output # 1-32

## Chime Zone Alarms to Outputs

**P131E 1-248E Chime Zone Alarms to Output**  
(Default = All Off) 01-32 = A Chime Zone Alarm will Turn On Output # 1-32

## Zone Tamper Alarms to Outputs

**P132E 1-248E Zone Tamper Alarms to Output**  
(Default = 1,2) 01-32 = A Zone Tamper Alarm will Turn On Output # 1-32

## Programming Zone Options D

**P6133E 1-248E Programming Zone Options D**  
(Default = All Off)

- 1 = Zone is Excluded from Activity monitoring
- 2 = Zone will hold off Arming until Sealed
- 3 = "Security Interlock" zone

## Armed Zone Alarm Beeps to Keypads

**P134E 1-248E Armed Zone Alarm Beeps to Keypads**  
(Default = All On) 01-32 = An Armed Zone Alarm will Beep Keypad #1-32



			Stay Mode Zone Alarm Beeps to Keypads
P135E	1-248E	<b>Stay Mode Zone Alarm Beeps to Keypads</b> (Default = All On)	01-32 = A Stay Mode Zone Alarm will Beep Keypad #1-32
			24 Hour Zone Alarm Beeps to Keypads
P136E	1-248E	<b>24 Hour Zone Alarm Beeps to Keypads</b> (Default = All On)	01-32 = A 24 Hour Zone Alarm will Beep Keypad #1-32
			Chime Zone Alarm Beeps to Keypads
P137E	1-248E	<b>Chime Zone Alarm Beeps to Keypads</b> (Default = All Off)	01-32 = A Chime Zone Alarm will Beep Keypad #1-32
			Zone Tamper Alarm Beeps to Keypads
P139E	1-248E	<b>Zone Tamper Alarm Beeps to Keypads</b> (Default = All On)	01-32 = A Zone Tamper Alarm will Beep Keypad #1-32
			Radio Supervise Alarm Beeps to Keypads
P140E	1-248E	<b>Radio Supervise Alarm Beeps to Keypads</b> (Default = All Off)	01-32 = A Radio Supervise Alarm will Beep Keypad #1-32
			Zone Sensor-watch Alarm Beeps to Keypads
P141E	1-248E	<b>Zone Sensor-watch Alarm Beeps to Keypads</b> (Default = All Off)	01-32 = A Zone Sensor-watch Alarm will Beep Keypad #1-32
			Armed Zone Entry Delay Beeps to Keypads
P142E	1-248E	<b>Armed Zone Entry Delay Beeps to Keypads</b> (Default = 1)	01-32 = Armed Zone Entry Delay will Beep Keypad #1-32
			Stay Mode Entry Delay Beeps to Keypads
P143E	1-248E	<b>Stay Mode Entry Delay Beeps to Keypads</b> (Default = 1)	01-32 = Stay Mode Entry Delay will Beep Keypad #1-32
			Armed Zone Entry Delay Times
P144E	1-248E	<b>Armed Zone Entry Delay Times</b> - Value 0-9999 seconds (Default Zone # 1 = 20 Seconds, Zones # 2-64 = 0)	
			Stay Mode Entry Delay Times
P145E	1-248E	<b>Stay Mode Entry Delay Times</b> - Value 0-9999 seconds (Default Zones # 1-4 = 20 Seconds, Zones # 5-64 = 0)	
			Zone Re-trigger Count
P146E	1-248E	<b>Zone Re-trigger Count</b> - Value 0-15 (Maximum number of times a zone can re-trigger during armed state. 0=Unlimited Triggers) (Default = 0)	
			Zone Reports using this Area
P147E	1-248E	<b>Zone Reports using this Area</b> - Value 0-32	
			Zone Alarm Contact ID Reporting Codes
P157E	1-248E	<b>Zone Alarm Contact ID Reporting Code</b> - (Default = 130)	
			Zone Near Alarm Contact ID Reporting Codes
P158E	1-248E	<b>Zone Near Alarm Contact ID Reporting Code</b> - (Default = 138)	
			Zone Intrusion Verified Alarm Contact ID Reporting Codes
P159E	1-248E	<b>Zone Intrusion Verified Alarm Contact ID Reporting Code</b> - (Default = 139)	
			Zone Alarm Voice Message Number
P160E	1-248E	<b>Zone Alarm Voice Message Number</b> - Value-0-99 (Default = 1)	
			Away Zone Entry Delay to Outputs
P161E	1-248E	<b>Away Zone Entry Delay to Outputs</b> (Default = All Off)	01-32 = Armed Zone Entry Delay to output #1-32
			Stay Mode Entry Delay to Outputs
P162E	1-248E	<b>Stay Mode Entry Delay Beeps to Outputs</b> (Default = All Off)	01-32 = Stay Mode Entry Delay to output #1-32
			Sensor-Watch Timer
P163E	1-248E	<b>Sensor-Watch Timer</b> - 0-9999 Minutes (Default = 7200 minutes [120 Hours])	
			Enrolling Radio Zone Codes
P164E	1-248E	<b>Learn Radio Zone Codes</b>	
			Delete a Specific Radio Zone Code
P165E	1-248E	<b>Delete a Specific Radio Zone Code</b>	
			Find Radio Zone memory Location
P166E		<b>This will find the zone # of any Radio Zone code stored in the panel</b> After P166E press enter to start the find process	
			Zone Near Alarm to Outputs
P167E	1-248E	<b>Zone Near Alarm to Outputs</b> (Default = All Off)	01-32 = Zone Near Alarm to output #1-32

## Zone Confirmed Alarm to Outputs

<b>P168E 1-248E</b>	<b>Zone Confirmed Alarm to Outputs</b> (Default = All Off)	01-32 = Zone Confirmed Alarm to output #1-32	
<b>P169E 1-248E</b>	<b>Program LCD KP "Zone" Name Text</b>		Program LCD KP "Zone" Name
<b>P6174E 1-248E</b>	<b>Access Control Door Monitor Linked to Output</b> (Default = All 0)	01-32 = Output #1-32 (0 = Disabled)	Access Control Door Monitor Linked to Output
<b>P6175E 1-248E</b>	<b>Access Control Options</b> (Default = 0)		Access Control Options 0 = Disabled, no access monitor options 1 = Access Door Monitoring 2 = Access Door REX button 3 = Egress button - hold door open 4 = Global Fire Egress - hold all Access doors open 5 = Global Egress - hold all Egress doors open
<b>P6176E 1-248E</b>	<b>Access Control Options B</b> (Default = None)		Access Control Options B 1 = Report access violation as output # not zone # 2 = Hide this zone on the web status page 3 = Zone restore auto-resets Egress outputs
<b>P6177E 1-248E</b>	<b>Access Door Open Too Long Beeps to Keypads</b> (Default = All Off)	01-32 = An Access Door left Open too long will Beep Keypad #1-32	Access Door Open Too Long Beeps to Keypads
<b>P6178E 1-248E</b>	<b>Access Door Forced Open Beeps to Keypads</b> (Default = All Off)	01-32 = An Access Door forced Open twill Beep Keypad #1-32	Access Door Forced Open Beeps to Keypads
<b>P6179E 1-248E</b>	<b>Access Door Open Too Long to Outputs</b> (Default = All Off)	01-32 = An Access Door left Open too long will trigger Output #1-32	Access Door Open Too Long to Outputs
<b>P6180E 1-248E</b>	<b>Access Door Forced Open to Outputs</b> (Default = All Off)	01-32 = An Access Door forced Open twill trigger Output #1-32	Access Door Forced Open to Outputs
<b>P6200E 1-248E</b>	<b>Manually enter or read the Shepherd (SH) device 7 digit ID number.</b>		SH Device Unique ID Number
<b>P6201E 1-248E</b>	<b>SH PIR Options</b> (Default = )		SH PIR Options 1 = Enable LED 2 = PET Mode 3 = Mute (Disable device detection)
<b>P6202E 1-248E</b>	<b>SH PIR Gain</b> (Default = )		SH PIR Gain 0 = Low 1 = Medium Low 2 = Medium 3 = Medium High 4 = High
<b>P6203E 1-248E</b>	<b>SH PIR Pulse Count</b> (Default = )		SH PIR Pulse Count 0 = 1 Pulse 1 = 2 Pulse 2 = 3 Pulse 3 = 1 Pulse, Time Filter Disabled
<b>P6204E 1-248E</b>	<b>SH PIR Supervise Interval</b> (Default = 0)		SH PIR Supervise Interval 0 = 7 Minutes (Default) 1 = 1 Minute 2 = 2 Minutes 3 = 4 Minutes 4 = 10 Minutes 5 = 15 Minutes 6 = 20 Minutes 7 = 30 Minutes
<b>P6211E 1-248E</b>	<b>SH MAG Options</b> (Default = )		SH MAG Options 1 = Enable LED 2 = Mute (Disable device detection) 3 = Logical AND between internal/external Magnet (Off = OR) 4 = Use Internal Magnet 5 = Use External Magnet
<b>P6212E 1-248E</b>	<b>SH MAG Supervise Interval</b> (Default = 0)		SH MAG Supervise Interval 0 = 7 Minutes (Default) 1 = 1 Minute 2 = 2 Minutes 3 = 4 Minutes 4 = 10 Minutes 5 = 15 Minutes

6 = 20 Minutes  
7 = 30 Minutes

## SH SMOKE Options

**P6221E 1-248E SH SMOKE Options**  
(Default = )

1 = Enable LED  
2 = Heat Detector Enable  
3 = Smoke Detector Enable  
4 = Mute (Disable device detection)

## SH SMOKE Supervise Interval

**P6222E 1-248E SH SMOKE Supervise Interval**  
(Default = 0)

0 = 7 Minutes  
1 = 1 Minute  
2 = 2 Minutes  
3 = 4 Minutes  
4 = 10 Minutes  
5 = 15 Minutes  
6 = 20 Minutes  
7 = 30 Minutes

## SH GLASSBREAK Options

**P6231E 1-248E SH GLASSBREAK Options**  
(Default = )

1 = Enable LED  
2 = Mute (Disable device detection)  
3 = Logical AND between Fall/Vibration sensors

## SH GLASSBREAK Sensitivity

**P6232E 1-248E SH GLASSBREAK Sensitivity**  
(Default = )

0 = Low  
1 = Medium Low  
2 = Medium  
3 = Medium High  
4 = High

## SH GBD Fall Sensitivity

**P6233E 1-248E SH GBD Fall Sensitivity**  
(Default = )

0 = Disable  
1 = Low  
2 = Medium  
3 = High

## SH GBD Vibration Sensitivity

**P6234E 1-248E SH GBD Vibration Sensitivity**  
(Default = )

0 = Disable  
1 = Low  
2 = Medium  
3 = High

## SH GLASSBREAK Supervise Interval

**P6235E 1-248E SH GBD Supervise Interval**  
(Default = 0)

0 = 7 Minutes (Default)  
1 = 1 Minute  
2 = 2 Minutes  
3 = 4 Minutes  
4 = 10 Minutes  
5 = 15 Minutes  
6 = 20 Minutes  
7 = 30 Minutes

## SH PIR-CAM Options

**P6241E 1-248E SH PIR-CAM Options**  
(Default = )

1 = Enable LED  
2 = PET Mode  
3 = Mute (Disable device detection)  
4 = Camera Enable  
5 = Differential JPEG Ratio  
6 = JPEG Mode  
7 = Contrast Enhanced  
8 = Sharpness Enhanced

## SH PIR-CAM Sensitivity

**P6242E 1-248E SH PIR-CAM Sensitivity**  
(Default = )

0 = Low  
1 = Medium Low  
2 = Medium  
3 = Medium High  
4 = High

## SH PIR-CAM Pulse Count

**P6243E 1-248E SH PIR-CAM Pulse Count**  
(Default = )

0 = 1 Pulse  
1 = 2 Pulse  
2 = 3 Pulse  
3 = 1 Pulse, Time Filter Disabled

## SH PIR-CAM Pictures per Set

**P6245E 1-248E SH PIR-CAM Pictures per Set**  
(Default = )

0 = 1 Picture  
1 = 2 Pictures  
2 = 3 Pictures  
3 = 4 Pictures  
4 = 5 Pictures

## SH PIR-CAM Picture Resolution

**P6246E 1-248E SH PIR-CAM Picture Resolution**  
(Default = )

0 = QVGA B&W (320x240)  
1 = VGA B&W (640x480)  
2 = QVGA Colour (320x240)

3 = T.B.D

### SH PIR-CAM Picture Rate

**P6247E 1-248E SH PIR-CAM Picture Rate**  
(Default = )

- 0 = 0.3 Seconds between images
- 1 = 0.5 Seconds between images
- 2 = 1.0 Seconds between images
- 3 = 1.4 Seconds between images
- 4 = 2.0 Seconds between images
- 5 = 5.0 Seconds between images
- 6 = 15 Seconds between images
- 7 = 30 Seconds between images

### SH PIR-CAM Hold-off Time

**P6248E 1-248E SH PIR-CAM Hold-off Time**  
(Default = )

- 0 = 30 Seconds
- 1 = 45 Seconds
- 2 = 60 Seconds
- 3 = 75 Seconds
- 4 = 105 Seconds
- 5 = 120 Seconds
- 6 = T.B.D

### SH PIR-CAM Picture Quality

**P6249E 1-248E SH PIR-CAM Picture Quality**  
(Default = )

- 0 = 20%
- 1 = 30%
- 2 = 40%
- 3 = 50%
- 4 = 60%
- 5 = 70%
- 6 = 80%
- 7 = 90%

### SH MAG/SHOCK Options

**P6270E 1-248E SH MAG/SHOCK Options**  
(Default = )

- 1 = Enable LED
- 4 = Use Internal Magnet
- 5 = Mute (Disable device detection)

### SH SHOCK Sensitivity

**P6271E 1-248E SH SHOCK Sensitivity**  
(Default = )

- 0 = Low
- 1 = Medium Low
- 2 = Medium
- 3 = Medium High
- 4 = High
- 5 = Shock sensor Disabled

### SH MAG/SHOCK Supervise Interval

**P6212E 1-248E SH MAG/SHOCK Supervise Interval**  
(Default = 0)

- 0 = 7 Minutes (Default)
- 1 = 1 Minute
- 2 = 2 Minutes
- 3 = 4 Minutes
- 4 = 10 Minutes
- 5 = 15 Minutes
- 6 = 20 Minutes
- 7 = 30 Minutes

### SH IO 2X2 Input Selection

**P6280E 1-248E SH IO 2X2 Input Selection**  
(Default = )

- 1 or 2

**(NOTE: The SH IO 2X2 box tamper will be associated with one, or both, zones if used.)**

### SH IO 2X2 Input EOL Mode

**P6281E 1-248E SH IO 2X2 Input EOL Mode**  
(Default = )

- 0 = Short Circuit
- 1 = 2K2

### SH RMT Button 2 (LOCK) Assign to Zone

**P6302E 1-248E SH RMT Button 2 Zone**

Zone 1-64 (Default = 0)

### SH RMT Button 3 (STAY-PA) Assign to Zone

**P6303E 1-248E SH RMT Button 3 Zone**

Zone 1-64 (Default = 0)

### SH RMT Button 4 (\*-PA) Assign to Zone

**P6304E 1-248E SH RMT Button 4 Zone**

Zone 1-64 (Default = 0)

## +++++Time Zones+++++

### Programming Holidays

**P170E 1-32E Holidays 1-32 Days - Value = DDMMYY**

### Programming Time Zone Days

**P171E 1-32E Time Zones 1-32 Days**  
(Default = All Off)

- 1 = Sunday
- 2 = Monday
- 3 = Tuesday
- 4 = Wednesday
- 5 = Thursday
- 6 = Friday
- 7 = Saturday
- 8 = Invert

## Programming Time Zone Start & End Times

**P172E 1-32E Time Zones 1-32 Start Time** - Value 0000-2359 (Default = 0000)

**P173E 1-32E Time Zones 1-32 End Time** - Value 0000-2359 (Default = 0000)

## Time Zone Options

**P174E 1-32E Time Zone 1-32 Options**

(Default = All Off)

- 1 = Ignore Holidays
- 2 = Dormant Time Zone (see P1032E)



## Dialler Programming Options

**P175E 1E Dialler options**

(Default = None)

- 1 = Dialler is Enabled
- 2 = Fax Defeat
- 3 = Disable Telephone Line Monitoring
- 4 = DTMF or Pulse Dial (**For DTMF, 4&5 must both be OFF**)
- 5 = DTMF or Reverse Pulse Dial (**For DTMF, 4&5 must both be OFF**)
- 6 = Send long DTMF tones during dialing
- 7 = Spare
- 8 = Spare

## Dialler Programming Options 2

**P175E 2E Dialler options 2**

(Default = 1)

- 1 = Step number on each call
- 2 = Spare
- 3 = Spare
- 4 = Test calls only if armed
- 5 = Test Time Period is in days
- 6 = Hold line open following Domestic/Voice report for DTMF control
- 7 = Ring Timeout (Off = 3 secs, On = 6.5 secs).
- 8 = Answer After 1 ring for Listen-in Mode

## Auto-Answer Ring Count

**P175E 3E Auto-Answer Ring Count** - Value 0-99 (Default = 25)

## Test Call Start Time

**P175E 4E Test Call Start Time** - Value 0000-2359 (Default = 2300)

## Test Call Time Period

**P175E 5E Test Time Call Period** - Value 0-255 Hours: 0 = No Test (Default = 24)

## Keypad Listen-in Options

**P175E 6E Keypad Listen-in Options**

(Default = 1,2,3,4,5,6,7)

- 1 = Enabled During Dialling in Disarm State only
- 2 = Enabled During Dialling in Armed State only
- 3 = Enabled During Dialling in Stay Mode State only
- 4 = Enabled Throughout the call in Disarm State only
- 5 = Enabled Throughout the call in Armed State only
- 6 = Enabled Throughout the call in Stay Mode State only
- 7 = Listen-in Enabled when the panel answers a call
- 8 = Enabled at All Times

## Dialler Fail Line Switch Output

**P175E 7E Dialler Fail Line Switch Output** - Value = Output number 1 –32

## Dialling Pre-fix Number

**P175E 8E Dialling Pre-fix Number** - Value 1-16 Digits (Default = 0)

## "Panic" Alarm Contact ID Reporting Code

**P175E 9E "Panic" Alarm CID Reporting Code** - (Default=120)

## "Fire" Alarm Contact ID Reporting Code

**P175E 10E "Fire" Alarm CID Reporting Code** - (Default=110)

## "Medical" Alarm Contact ID Reporting Code

**P175E 11E "Medical" Alarm CID Reporting Code** - (Default=100)

## Output "Command Control" Code Number

**P175E 12E Output Command Control code** - Value 1-4 digit code (1-9999) (Default = 0)

## Microphone On/Off "Command Control" Code Number

**P175E 13E Reserved for future use.**

## Dialler Acknowledge Code

**P175E 14E Voice/Domestic Acknowledge Code** - Value 1-4 digit code (1-9999) (Default = 0)

## Force Test Call Code

**P175E 15E Force Test Call Code** - Value 1-4 digit code (1-9999) (Default = 0, Feature disabled)

## Programming Voice Board Messages

P176E	1E	<b>Keypad or Radio "Panic" Alarm Voice Message Number</b> - Value 0-99 (Default = 0)
P176E	2E	<b>"Fire" Alarm Voice Message Number</b> - Value 0-99 (Default = 0)
P176E	3E	<b>"Medical" Alarm Voice Message Number</b> - Value 0-99 (Default = 0)
P176E	4E	<b>"Mains Failure" Voice Message Number</b> - Value 0-99 (Default = 0)
P176E	5E	<b>"Mains Restore" Voice Message Number</b> - Value 0-99 (Default = 0)
P176E	6E	<b>"Battery Low" Voice Message Number</b> - Value 0-99 (Default = 0)
P176E	7E	<b>"Battery Restored" Voice Message Number</b> - Value 0-99 (Default = 0)
P176E	8E	<b>"Tamper" (Zone/Radio/System) Voice Message Number</b> - Value 0-99 (Default = 0)
P176E	9E	<b>"Duress Alarm" Voice Message Number</b> - Value 0-99 (Default = 0)
P176E	10E	<b>"Latchkey Disarm" Voice Message Number</b> - Value 0-99 (Default = 0)
P176E	11E	<b>"Manual Test Initiated" Voice Message Number</b> - Value 0-99 (Default = 0)

## +++++Telephone Numbers+++++

### Programming Telephone Numbers

P181E	1-8E	<b>Programming Telephone Numbers</b> - Value 1-16 Digits (Default = 0)
-------	------	--

### Telephone Number Reporting Formats

P182E	1-8E	<b>Telephone Number Reporting Formats</b> (Default = 1)	<ul style="list-style-type: none"><li>1 = Contact ID</li><li>2 = Domestic Dial</li><li>3 = Pager</li><li>4 = Speech Dialler</li><li>5 = CSV IP Extended (sends 4 digit zone/user field)</li><li>6 = Patriot IP</li><li>7 = XML IP</li><li>8 = CSV IP Normal</li><li>9 = Spare</li><li>10 = SIA Format</li><li>11 = SIA Slow Format</li></ul>
-------	------	--	--

### Telephone Number Reporting Options

P183E	1-8E	<b>Telephone Number Reporting Options</b> (Default = 1,2)	<ul style="list-style-type: none"><li>1 = Stop Dialling if Kissed off</li><li>2 = Monitor Call Progress</li><li>3 = Blind Dial</li><li>4 = Use Group Numbers for Contact ID Reporting</li><li>5 = Stay On-line after Alarm report for Audio Listen-in</li><li>6 = Spare</li><li>7 = Use the Dialling Pre-fix</li><li>8 = Spare</li></ul>
-------	------	--	--

### Maximum Dial Attempts per Telephone Number

P184E	1-8E	<b>Maximum Dial Attempts per Telephone Number</b> - Value 0-99 (Default = 20)
-------	------	---

### Dialler Reporting Options A

P186E	1-8E	<b>Dialler Options A</b> (Default = All On)	<ul style="list-style-type: none"><li>1 = Report Mains Failure</li><li>2 = Report Battery low</li><li>3 = Report Radio Battery Low</li><li>4 = Report Line Fail</li><li>5 = Report System Tamper</li><li>6 = Report Keypad Tamper</li><li>7 = Report Zone Tamper</li><li>8 = Report Radio Zone Tamper</li></ul>
-------	------	--	---

### Dialler Reporting Options B

P187E	1-8E	<b>Dialler Options B</b> (Default = All On)	<ul style="list-style-type: none"><li>1 = Report Duress Alarm</li><li>2 = Report Supervised Radio Alarm</li><li>3 = Report Zone Sensor-watch Alarm</li><li>4 = Report Manual Panic Alarm</li><li>5 = Report Manual Fire Alarm</li><li>6 = Report Manual Medical Alarm</li><li>7 = Report Radio Pendant Panic Alarm</li><li>8 = Report Zone Bypasses</li></ul>
-------	------	--	---

### Dialler Reporting Options C

P188E	1-8E	<b>Dialler Options C</b> (Default = 1,6,8)	<ul style="list-style-type: none"><li>1 = Report Arm/Disarm</li><li>2 = Report Stay Mode Arm/Disarm</li><li>3 = Report Disarm only after an Activation</li><li>4 = Report Stay Mode Disarm only after an Activation</li><li>5 = Report Stay Mode Zone Alarms</li><li>6 = Report Access to Program Mode</li><li>7 = Report 24 Hour Alarms when set to Domestic/Voice mode</li><li>8 = Report Zone Restores</li></ul>
-------	------	---	---

### Dialler Reporting Options D

P189E	1-8E	<b>Dialler Options D</b> (Default = 3,4,5)	<ul style="list-style-type: none"><li>1 = Report Latchkey Disarm</li><li>2 = Report Delinquent</li><li>3 = Report Tests</li><li>4 = Report Fuse Failure</li><li>5 = Report Output 1 or 2 Fail</li></ul>
-------	------	---	---

6 = Report RTC Time changed  
 7 = Report Keypad Buss Trouble  
 8 = Report RF Interference (Jamming) Detected

## ++++SIA Alarm Report Codes++++

(SIA event codes are entered by programming a value from the chart on Page 23. For example, to send the SIA "Panic Alarm" code when a keypad panic is generated you must enter a value of "6" at location P197E1E)

### Zone Alarm SIA Reporting Codes

- |              |               |  |
|--------------|---------------|--|
| <b>P196E</b> | <b>1-248E</b> | <b>Zone Alarm SIA Reporting Code</b> - (Default value = 1, Alarm Event Code BA)              |
|              |               | "Panic" Alarm SIA Reporting Code   |
| <b>P197E</b> | <b>1E</b>     | <b>"Panic" Alarm SIA Reporting Code</b> - (Default value = 6, Panic Alarm Event Code PA)     |
|              |               | "Fire" Alarm SIA Reporting Code  |
| <b>P197E</b> | <b>2E</b>     | <b>"Fire" Alarm SIA Reporting Code</b> - (Default value = 4, Fire Alarm Event Code FA)       |
|              |               | "Medical" Alarm SIA Reporting Code   |
| <b>P197E</b> | <b>3E</b>     | <b>"Medical" Alarm SIA Reporting Code</b> - (Default value = 5, Medical Alarm Event Code MA) |

## ++++Panel Diagnostic & Default Options++++

- |              |                 |   |  |   |
|--------------|-----------------|---|--|---|
| <b>P200E</b> | <b>1E</b>       | <b>Display the Panel Software Version Number</b>                            |  | Display Panel Software Version Number                             |
| <b>P200E</b> | <b>2E</b>       | <b>Display Keypad Address Number</b>  |  | Display Keypad Address Number                                     |
| <b>P200E</b> | <b>3E</b>       | <b>Display Areas Assigned to this Keypad</b>                                |  | Display Areas Assigned to this Keypad                             |
| <b>P200E</b> | <b>4E</b>       | <b>Display Active Time Zones</b>  |  | Display Active Time Zones   |
| <b>P200E</b> | <b>5E</b>       | <b>Display Battery Voltage</b>  |  | Display Battery Voltage   |
| <b>P200E</b> | <b>6E</b>       | <b>Walk Test Mode</b>   |  | Walk Test Mode  |
| <b>P200E</b> | <b>7E</b>       | <b>Update "Firmware" to LCD KP, Zone and Output Expanders</b>               |  | Update "Firmware" to LCD KP, Zone and Output Expanders            |
| <b>P200E</b> | <b>8E</b>       | <b>Update "text Files" to LCD Keypads</b>                                   |  | Update "Text Files" to LCD Keypads                                |
| <b>P200E</b> | <b>9E</b>       | <b>Restore User/Installer Codes &amp; Telephone #'s to Default Values</b>   |  | Restore User & Installer Codes plus Telephone Numbers to Defaults |
| <b>P200E</b> | <b>10E</b>      | <b>Restore All Factory Defaults (excludes LCD text)</b>                     |  | Restore All Factory Defaults                                      |
| <b>P200E</b> | <b>11E</b>      | <b>Clear Alarm Memory Buffer</b>  |  | Clear Alarm Memory Buffer   |
| <b>P200E</b> | <b>12E</b>      | <b>Default ALL LCD text.</b>  |  | Default ALL LCD text  |
| <b>P200E</b> | <b>14E</b>      | <b>Read RSSI from Pendants and Wireless Zones</b>                           |  | Read RSSI from Pendants and Wireless Zones                        |
| <b>P200E</b> | <b>15E</b>      | <b>Reset Keypad Bus to restart all bus connected devices</b>                |  | Reset Keypad Bus  |
| <b>P200E</b> | <b>16E</b>      | <b>Update EC-KP Firmware for all EC-KP's connected to the Keypad Bus</b>    |  | Update EC-KP firmware   |
| <b>P200E</b> | <b>17E1234E</b> | <b>Reset ALL Site/User details on the AAP Server to allow new ownership</b> |  | Clear ALL Site/User details on the APP Server for this panel      |
|              |                 | <b><u>NOTE: The Panel MUST have an internet connection to work.</u></b>     |  |   |

## +++++IP Alarm Setup+++++

P201E 1E	<b>Control Panel IP Address</b> (Can also be viewed by pressing the number "9" for 5 seconds in normal mode)	Panel IP Address
P201E 2E	<b>IP Gateway Address</b> (Default = 000.000.000.000)	IP Gateway Address
P201E 3E	<b>IP Subnet Mask</b> (Default = 255.255.255.000)	IP Subnet Mask
P201E 4E	<b>IP Setup Options</b> (Default = All Off) 1 = DHCP/Manual Panel IP address (Off = Automatic DHCP) 2 = Enable Ethernet Test 3 = Sync Panel to Internet Clock 4 = Enable Serial over IP Communications 5 = Disable Cloud Connection (On = No Cloud connection) 6 = Disable Web Pages (On = Web Pages disabled) 7 = Spare 8 = Spare	IP Setup Options
P201E 5E	<b>Show Panel MAC Address</b> (Can also be viewed by pressing the number "8" for 5 seconds in normal mode)	Show Panel MAC Address
P201E 6E	<b>CSV IP Name</b>	CSV IP Name
P201E 7E	<b>CSV IP Password</b>	CSV IP Password
P201E 8E	<b>Alternative (Secondary) Gateway</b> (Default = 000.000.000.000)	Alternative Gateway
P201E 9E	<b>DNS 1</b> (Default: 8.8.8.8)	Primary DNS Server
P201E 10E	<b>DNS 2</b> (Default: 8.8.4.4)	Secondary DNS Server
P201E 11E	<b>NTP 1</b> (Default: 0.nz.pool.ntp.org)	Primary Time Server
P201E 12E	<b>NTP 2</b> (Default: 1.nz.pool.ntp.org)	Secondary Time Server
P201E 13E	<b>Serial over IP Port</b> (Default: 9000)	Serial over IP Port
P201E 14E	<b>Web Port Number</b> (Default: 80)	Web Port Number
P202E 1-8E	<b>IP Reporting Poll Timer (0-9999 minutes)</b>	IP Reporting Poll Timer
P203E 1-8E	<b>Monitoring IP Reporting Number/URL (000.000.000.000)</b>	Monitoring IP Reporting Number/URL
P204E 1-8E	<b>IP Reporting Port Number</b>	IP Reporting Port Number
P205E 1-8E	<b>IP Reporting Poll Event Code</b>	IP Reporting Port Number



Elite-SX Status Activity Settings Logout

## Access group edit

Access group number:  Read Save Prev Next

### Access group schedules

Output	Output Name	Schedule
Output 1 (Location P3101E)	Output 1	ENABLE 24/7
Output 2 (Location P3102E)	Output 2	--- NONE ---
Output 3 (Location P3103E)	Output 3	--- NONE ---
Output 4 (Location P3104E)	Output 4	--- NONE ---
Output 5 (Location P3105E)	Output 5	Schedule 10
Output 6 (Location P3106E)	Output 6	--- NONE ---
Output 7 (Location P3107E)	Output 7	--- NONE ---
Output 8 (Location P3108E)	Output 8	Schedule 15
Output 9 (Location P3109E)	Output 9	--- NONE ---
Output 10 (Location P3110E)	Output 10	--- NONE ---
Output 11 (Location P3111E)	Output 11	--- NONE ---
Output 12 (Location P3112E)	Output 12	Schedule 32
Output 13 (Location P3113E)	Output 13	--- NONE ---
Output 14 (Location P3114E)	Output 14	--- NONE ---
Output 15 (Location P3115E)	Output 15	--- NONE ---
Output 16 (Location P3116E)	Output 16	--- NONE ---
Output 17 (Location P3117E)	Output 17	--- NONE ---
Output 18 (Location P3118E)	Output 18	--- NONE ---
Output 19 (Location P3119E)	Output 19	--- NONE ---
Output 20 (Location P3120E)	Output 20	--- NONE ---
Output 21 (Location P3121E)	Output 21	--- NONE ---
Output 22 (Location P3122E)	Output 22	--- NONE ---
Output 23 (Location P3123E)	Output 23	--- NONE ---
Output 24 (Location P3124E)	Output 24	--- NONE ---
Output 25 (Location P3125E)	Output 25	--- NONE ---
Output 26 (Location P3126E)	Output 26	--- NONE ---
Output 27 (Location P3127E)	Output 27	--- NONE ---
Output 28 (Location P3128E)	Output 28	--- NONE ---
Output 29 (Location P3129E)	Output 29	--- NONE ---
Output 30 (Location P3130E)	Output 30	--- NONE ---
Output 31 (Location P3131E)	Front Door OP#31	Schedule 1
Output 32 (Location P3132E)	Store Door OP#32	Schedule 2

Hint: Outputs without an access schedule selected above are excluded from this access group.

# Zone Expander DIP Switch settings

Expanders - Zone Doubling	Expanders - NO Zone Doubling	DIP SW1	DIP SW2	DIP SW3	DIP SW4	DIP SW5	DIP SW6	DIP SW7	DIP SW8
Not used	EXP # 1 (zones 9-16)	<u>ON</u>	off	off	off	off			
EXP # 2 (zones 17-32)	EXP # 2 (zones 17-24)	off	<u>ON</u>	off	off	off			
Not used	EXP # 3 (zones 25-32)	<u>ON</u>	<u>ON</u>	off	off	off			
EXP # 4 (zones 33-48)	EXP # 4 (zones 33-40)	off	off	<u>ON</u>	off	off			
Not used	EXP # 5 (zones 41-48)	<u>ON</u>	off	<u>ON</u>	off	off			
EXP # 6 (zones 49-64)	EXP # 6 (zones 49-56)	off	<u>ON</u>	<u>ON</u>	off	off			
Not used	EXP # 7 (zones 57-64)	<u>ON</u>	<u>ON</u>	<u>ON</u>	off	off			
EXP # 8 (zones 65-80)	EXP # 8 (zones 64-72)	off	off	off	<u>ON</u>	off			
Not used	EXP # 9 (zones 72-80)	<u>ON</u>	off	off	<u>ON</u>	off			
EXP # 10 (zones 81-96)	EXP # 10 (zones 81-88)	off	<u>ON</u>	off	<u>ON</u>	off			
Not used	EXP # 11 (zones 89-96)	<u>ON</u>	<u>ON</u>	off	<u>ON</u>	off			
EXP # 12 (zones 97-112)	EXP # 12 (zones 97-104)	off	off	<u>ON</u>	<u>ON</u>	off			
Not used	EXP # 13 (zones 105-112)	<u>ON</u>	off	<u>ON</u>	<u>ON</u>	off			
EXP # 14 (zones 113-128)	EXP # 14 (zones 113-120)	off	<u>ON</u>	<u>ON</u>	<u>ON</u>	off			
Not used	EXP # 15 (zones 121-128)	<u>ON</u>	<u>ON</u>	<u>ON</u>	<u>ON</u>	off			
EXP # 16 (zones 129-144)	EXP # 16 (zones 129-136)	off	off	off	off	<u>ON</u>			
Not used	EXP # 17 (zones 137-144)	<u>ON</u>	off	off	off	<u>ON</u>			
EXP # 18 (zones 145-160)	EXP # 18 (zones 145-152)	off	<u>ON</u>	off	off	<u>ON</u>			
Not used	EXP # 19 (zones 153-160)	<u>ON</u>	<u>ON</u>	off	off	<u>ON</u>			
EXP # 20 (zones 161-176)	EXP # 20 (zones 161-168)	off	off	<u>ON</u>	off	<u>ON</u>			
Not used	EXP # 21 (zones 169-176)	<u>ON</u>	off	<u>ON</u>	off	<u>ON</u>			
EXP # 22 (zones 177-192)	EXP # 22 (zones 177-184)	off	<u>ON</u>	<u>ON</u>	off	<u>ON</u>			
Not used	EXP # 23 (zones 185-192)	<u>ON</u>	<u>ON</u>	<u>ON</u>	off	<u>ON</u>			
EXP # 24 (zones 193-208)	EXP # 24 (zones 193-200)	off	off	off	<u>ON</u>	<u>ON</u>			
Not used	EXP # 25 (zones 201-208)	<u>ON</u>	off	off	<u>ON</u>	<u>ON</u>			
EXP # 26 (zones 209-224)	EXP # 26 (zones 209-216)	off	<u>ON</u>	off	<u>ON</u>	<u>ON</u>			
Not used	EXP # 27 (zones 217-224)	<u>ON</u>	<u>ON</u>	off	<u>ON</u>	<u>ON</u>			
EXP # 28 (zones 225-240)	EXP # 28 (zones 225-232)	off	off	<u>ON</u>	<u>ON</u>	<u>ON</u>			
Not used	EXP # 29 (zones 233-240)	<u>ON</u>	off	<u>ON</u>	<u>ON</u>	<u>ON</u>			
EXP # 30 (zones 241-248)	EXP # 30 (zones 241-248)	off	<u>ON</u>	<u>ON</u>	<u>ON</u>	<u>ON</u>			
	On Board Tamper Ignored								<u>ON</u>
	On Board Tamper Active								off

# Output Expander DIP Switch settings

Output Expander Number	DIP SW1	DIP SW2	DIP SW3	DIP SW4	DIP SW5	DIP SW6	DIP SW7	DIP SW8
O/P EXP # 1	off	off	off	Follows Outputs 1-4				
O/P EXP # 2	<u>ON</u>	off	off	Follows Outputs 5-8				
O/P EXP # 3	off	<u>ON</u>	off	Follows Outputs 9-12				
O/P EXP # 4	<u>ON</u>	<u>ON</u>	off	Follows Outputs 13-16				
O/P EXP # 5	off	off	<u>ON</u>	Follows Outputs 17-20				
O/P EXP # 6	<u>ON</u>	off	<u>ON</u>	Follows Outputs 21-24				
O/P EXP # 7	off	<u>ON</u>	<u>ON</u>	Follows Outputs 25-28				
O/P EXP # 8	<u>ON</u>	<u>ON</u>	<u>ON</u>	Follows Outputs 29-32				
On Board Tamper Ignored								<u>ON</u>
On Board Tamper Active								off

DIP switch number 8 disables the on-board tamper input if not required.  
DIP Switches 4, 5, 6, & 7 are currently unused.

There is an LED associated with every output. They are labelled OUTPUT 1-4.  
LED 1 relates to output 1 through to LED 4 relates to output 4.

At power up the LED's will cycle in numerical order back and forth until communications is established with the main control panel. If there is an address clash (eg two output expanders set to the same address number) they will continue to cycle until the clash is resolved by changing the switches on one of the expanders.

Under normal conditions the LED's will be off when the output is off. When an LED is on that indicates the associated relay is on.

The output expander can be powered from the main control panel (as shown on the connection diagram on the previous page) or there is an optional plug in 1A power supply module that can be fitted to the output expander. When the optional power supply module is fitted the 13.8V (POS) from the panel must not be connected, only the 0V from the main control panel should be connected to the output expander 0V.

# EC-A2 Interface DIP Switch settings

EC-A2 Keypad Address	DIP SW1	DIP SW2	DIP SW3	DIP SW4	DIP SW5	Relay Mapped to	Input Mapped to
Keypad Address # 1	off	off	off	off	off	Output 1	Input 1
Keypad Address # 2	<u>ON</u>	off	off	off	off	Output 2	Input 2
Keypad Address # 3	off	<u>ON</u>	off	off	off	Output 3	Input 3
Keypad Address # 4	<u>ON</u>	<u>ON</u>	off	off	off	Output 4	Input 4
Keypad Address # 5	off	off	<u>ON</u>	off	off	Output 5	Input 5
Keypad Address # 6	<u>ON</u>	off	<u>ON</u>	off	off	Output 6	Input 6
Keypad Address # 7	off	<u>ON</u>	<u>ON</u>	off	off	Output 7	Input 7
Keypad Address # 8	<u>ON</u>	<u>ON</u>	<u>ON</u>	off	off	Output 8	Input 8
Keypad Address # 9	off	off	off	<u>ON</u>	off	Output 9	Input 9
Keypad Address # 10	<u>ON</u>	off	off	<u>ON</u>	off	Output 10	Input 10
Keypad Address # 11	off	<u>ON</u>	off	<u>ON</u>	off	Output 11	Input 11
Keypad Address # 12	<u>ON</u>	<u>ON</u>	off	<u>ON</u>	off	Output 12	Input 12
Keypad Address # 13	off	off	<u>ON</u>	<u>ON</u>	off	Output 13	Input 13
Keypad Address # 14	<u>ON</u>	off	<u>ON</u>	<u>ON</u>	off	Output 14	Input 14
Keypad Address # 15	off	<u>ON</u>	<u>ON</u>	<u>ON</u>	off	Output 15	Input 15
Keypad Address # 16	<u>ON</u>	<u>ON</u>	<u>ON</u>	<u>ON</u>	off	Output 16	Input 16
Keypad Address # 17	off	off	off	off	<u>ON</u>	Output 17	Input 17
Keypad Address # 18	<u>ON</u>	off	off	off	<u>ON</u>	Output 18	Input 18
Keypad Address # 19	off	<u>ON</u>	off	off	<u>ON</u>	Output 19	Input 19
Keypad Address # 20	<u>ON</u>	<u>ON</u>	off	off	<u>ON</u>	Output 20	Input 20
Keypad Address # 21	off	off	<u>ON</u>	off	<u>ON</u>	Output 21	Input 21
Keypad Address # 22	<u>ON</u>	off	<u>ON</u>	off	<u>ON</u>	Output 22	Input 22
Keypad Address # 23	off	<u>ON</u>	<u>ON</u>	off	<u>ON</u>	Output 23	Input 23
Keypad Address # 24	<u>ON</u>	<u>ON</u>	<u>ON</u>	off	<u>ON</u>	Output 24	Input 24
Keypad Address # 25	off	off	off	<u>ON</u>	<u>ON</u>	Output 25	Input 25
Keypad Address # 26	<u>ON</u>	off	off	<u>ON</u>	<u>ON</u>	Output 26	Input 26
Keypad Address # 27	off	<u>ON</u>	off	<u>ON</u>	<u>ON</u>	Output 27	Input 27
Keypad Address # 28	<u>ON</u>	<u>ON</u>	off	<u>ON</u>	<u>ON</u>	Output 28	Input 28
Keypad Address # 29	off	off	<u>ON</u>	<u>ON</u>	<u>ON</u>	Output 29	Input 29
Keypad Address # 30	<u>ON</u>	off	<u>ON</u>	<u>ON</u>	<u>ON</u>	Output 30	Input 30
Keypad Address # 31	off	<u>ON</u>	<u>ON</u>	<u>ON</u>	<u>ON</u>	Output 31	Input 31
Keypad Address # 32	<u>ON</u>	<u>ON</u>	<u>ON</u>	<u>ON</u>	<u>ON</u>	Output 32	Input 32

OPTION	DIP SW6	DIP SW7	DIP SW8	
1 Door Controller	off	-		If set to 1 door Wiegand Input 2 unused
2 Door Controller	<u>ON</u>	-		If set to 2 door Wiegand Input 2 is KP address +1
Input is a REX	-	off		If set to 1 door only Input 1 is active, if set to 2 door both inputs are REX
Input is a Zone	-	<u>ON</u>		If set to 1 door only Input 1 is active, if set to 2 door both inputs are zones
Enable EC-A2 Tamper	-	-	off	EC-A2 on-board tamper is active and will trigger an alarm
Disable EC-A2 Tamper	-	-	<u>ON</u>	If DIP SW8 is ON the EC-A2 tamper is disabled

# Contact ID Reporting Code Summary

In addition to the programmable Contact ID Event Code assignments defined at P157E, P158E, P159E, P175E (9E-11E) there are a number of fixed event codes. The programmable and fixed event codes are all listed in the table below. Associated with the fixed and programmable event codes, there are a number of extension codes, that are also listed below. The list of extension codes is for your reference only and can not be changed in programming. For "Users" Above 998 the panel will report all as user 998 (eg users 998-2000 will all be reported as 998).

Event Type	Event Code	Extension	Comment
System Tamper	137	000	Panel & Sat Tamper etc
Zone Alarm (wired or wireless)	130	001 to 248	Alarm on Zone 1-248
Zone Tamper - Low (short circuit)	383	001 to 248	Zone Input 1-248 short circuit
Zone Tamper - High (open circuit)	383	009 to 248	Zone Input 1-248 open circuit
Zone Tamper - Radio Zone	383	001 to 248	Radio Zone 1-248
Zone Near Alarm	138	001 to 248	Zone Input 1-248
Zone Confirmed Alarm	139	001 to 248	Zone Input 1-248
Radio PIR / Reed Switch Battery Low	384	001 to 248	Radio Zone 1-248
Radio PIR Supervised Alarm	381	001 to 248	Supervised Radio Zone 1-248
Sensor-watch Alarm	391	001 to 248	Zone 1-248
Zone Excludes	570	001 to 248	Exclude Zone 1-248
Keypad Panic (CONTROL+CHIME)	120	001 to 032	Panic at keypad #1-32
Radio-Key Panic	120	101 to 998	Panic by Radio User # 101-2000
Keypad Fire (A+B)	110	001 to 032	Fire Alarm at keypad #1-32
Keypad Medical (B+CHIME)	100	001 to 032	Medical Alarm at keypad #1-32
Keypad Tamper Switch Alarm	137	001 to 032	Keypad 1-32 Tamper Switch Activated
Wrong Code Alarm	461	001 to 032	4 Incorrect code entries at KP # 1-32
Arm/Disarm by "ARM key (Quick Arm)	408	000	Arm/Disarm by single button
Arm/Disarm by user code	401	001 to 998	Arm/Disarm by User #1-2000
Arm/Disarm by Radio-key	400	101 to 998	Arm/Disarm by Radio User #101-2000
Arm/Disarm by Key-switch	409	001 to 064	Zone Key-switch # 1-64 Arm/Disarm
Arm/Disarm by DTMF or Up/Download	407	000	Remote Arm/Disarm
Arm by "Security Interlock" Zone	407	001 to 064	Arm by "Security Interlock" zone # 1-64
Arm/Disarm by Time-Zone	403	000	Time-Zone Arm/Disarm
Latchkey Disarm	642	001 to 998	Latchkey User Disarm
Fail to Arm on Time-Zone	455	000	Auto Arm fail
Delinquency Alarm	454	000	System not Armed within # days
Stay Mode Arm/Disarm (part set)	441	000	Arm by "Stay" Button
Stay Mode Arm/Disarm (part set)	441	001 to 998	Stay Mode Arm by User # 1-2000
Stay Mode Arm/Disarm by Key-switch	442	000 to 064	Stay Mode Arm by Zone Key-switch # 1-64
AC Fail	301	000	Mains (AC) fail
Zone Expander AC Fail	301	001-007	AC Fail on Zone exp. 1-7
Output Expander AC Fail	301	101-108	AC Fail on Output exp. 1-8
Wiegand Interface AC Fail	301	201-232	AC Fail on Wiegand IF 1-32
System Battery Low	302	000	Control Panel Battery low
Zone Expander Battery Low	302	001-007	Battery Low on Zone exp. 1-7
Output Expander Battery Low	302	101-108	Battery Low on Output exp. 1-8
Wiegand Interface Battery Low	302	201-232	Battery Low on Wiegand IF 1-32
Checksum Fail (Corrupt EEPROM Data)	303	001-008	Checksum block error
Fuse Fail - Main panel	312	000	Fuse 1 or 2 Fail on ESX-1
Fuse Fail - Zone expander	312	001-007	Fuse Fail on Zone Exp PSU
Fuse Fail - Output expander	312	101-108	Fuse Fail on Output EXP PSU
Fuse Fail - Wiegand IF-2	312	201-232	Fuse Fail on Wiegand IF-2 PSU
Radio-key Battery Low	309	101 to 998	Radio-key User #101-2000 low batt.
Radio-PIR / Reed Switch Battery Low	384	001 to 064	Radio Zone 1-64
Radio Output Device Battery Low	338	001 to 032	Radio Output 1-32
Automatic TEST Calls	602	000	24 hour test
Manual TEST Calls	601	000	User generated Test Call
Phone Line Failure	351	000	Reported when line is restored
IP Communication Failure	351	002	Reported when IP Comms restore
Duress Alarm	121	001 to 032	Duress at Keypad #1-32
Program Mode Entry	627	000	Program Mode entered
Program Mode Exit	628	000	Program Mode exited
Zone Expander Tamper Alarm	145	001-007	Zone expander board Tamper Alarm
Output Expander Tamper Alarm	341	001-008	Output expander board Tamper Alarm
Wiegand IF-2 Tamper Alarm	137	001-032	Wiegand IF-2 board Tamper Alarm
Zone Expander Module Fail	333	001-007	Zone exp. 1-7 Fail
Output Expander Module Fail	333	101-108	Output exp. 1-8 Fail
Wiegand Interface Module Fail	333	201-232	Wiegand IF 1-32 fail
FW2-CAN bus RF Module Fail	333	100	The FW2 CAN bus RF Module is missing

Output 1 or 2 Tamper	323	001 or 002	O/P 1 or 2 wires cut.
Time & Date Changed	625	000	Time & Date has been changed
Keypad Bus Trouble	330	001 to 032	Keypad device 1-32 offline
System Reset	305	000	Panel has rebooted
RF Receiver jam detected	344	000	RF Jamming Detected
Dialler Failure	354	000	Failure to get kiss off
IP Failure	356	000	Failure to send IP Poll
Access Door Forced Alarm	423	001 to 032	The access door has been forced open
Access Door left open too long Alarm	426	001 to 032	The access door has been left open.
Access Door opened by Fire alarm input	125	001 to 064	Free Egress granted during a Fire Alarm

# SIA Reporting Code Summary

Most of the SIA Event Codes are fixed within the panel but some locations such as zones at P196E (1-248E) and Panic/Fire/Medical at P197E (1-3E) can have a user defined report code from the table below. To follow are the default SIA reporting codes. Unlike CID, users 1-2000 will be reported as 1-2000 in SIA format.

Event Type	SIA Alarm Code	SIA Restore Code
Armed, 24 hour & Near Zone Alarms ( <u>programmable P196E</u> )	BA	BH
Zone Verified Alarm Activated	BV	BH
Zone Bypassed	BB	BU
Zone Tamper Activated	BT	BJ
Sensor-Watch Fail	NA	NS
Radio Zone Supervise Fail	BZ	BR
Pendant or Radio Zone Low Battery	XT	XR
Keypad or Pendant Panic Alarm ( <u>programmable P197E1E</u> )	PA	PH
Keypad Fire Alarm ( <u>programmable P197E2E</u> )	FA	FH
Medical Alarm ( <u>programmable P197E3E</u> )	MA	MH
Duress Alarm	HA	HH
Panel, Keypad or Wiegand IF-2 Tamper Switch Activated	TA	TR
Zone Expander Tamper Activated	ES	EJ
Output Expander Tamper Activated	TT	TJ
Zone, Output or Wiegand IF-2 fail	EM	EN
Battery Low (see CID for extension numbers)	YT	YR
AC Fail (see CID for extension numbers)	AT	AR
Output Tamper Alarm (O/P 1 & 2 only)	YA	YH
12V Output (fuse) Failure	YP	YQ
Phone Line Fail	LT	LR
Automatic Test Message	RP	
Manual Test Call	RX	
Area Delinquency Alarm	CD	CT
Excessive Code Attempts Alarm	JA	JP
Armed by User, Pendant, ARM button, DTMF or PC	CL	OP
Area Armed by Key-Switch	CS	OS
Area Armed by Time Zone	CA	OA
Stay Mode Armed by User, Pendant, KS, STAY Button	CG	OG
Fail to Arm by Time-Zone	CI	
Program Mode Entry/Exit	LB	LX
Checksum Fail (Corrupt EEPROM Data)	YF	
Time Changed	JT	
Keypad Bus Trouble	IA	IR
Dialler Failure (No Kiss off)	YC	
RF Interference (jamming) Detected	XQ	XH
IP Poll Failure	NT	NR
Access Door Forced Alarm	DF	DR
Access Door Left Open too Long	DN	DH
Egress Door Opened by Pushbutton or Fire alarm	DG	DY

When you program one of the numbers in column 2 below at any of the addresses at P196E or P197E then all of the SIA codes associated with that event type will automatically be loaded, eg if Zone 10 (P196E10E) was programmed with a "4", then when zone 10 activates it will send the fire alarm (FA) and the fire alarm restore (FH) and if zone 10 was bypassed it will send the fire bypass (FB) and the fire un-bypass (FU).

<b>CHART FOR THE PROGRAMMABLE SIA EVENT CODES</b>									
Event Description	Program Number	Alarm	Restore	Bypass	Un-Bypass	Trouble	Trouble Restore	Near Alarm	Verified Alarm
Burglary	<b>1</b>	BA	BH	BB	BU	BT	BJ	BA	BV
Un-typed Alarm	<b>2</b>	UA	UH	UB	UU	UT	UJ	-	-
Hold-up	<b>3</b>	HA	HH	HB	HU	HT	HJ	-	-
Fire	<b>4</b>	FA	FH	FB	FU	FT	FJ	FA	FM
Medical	<b>5</b>	MA	MH	MB	MU	MT	MJ	-	-
Panic	<b>6</b>	PA	PH	PB	PU	PT	PJ	-	-
Emergency	<b>7</b>	QA	QH	QB	QU	QT	QJ	-	-
Gas	<b>8</b>	GA	GH	GB	GU	GT	GJ	-	-
Sprinkler	<b>9</b>	SA	SH	SB	SU	ST	SJ	-	-
Water	<b>10</b>	WA	WH	WB	WU	WT	WJ	-	-
Heat	<b>11</b>	KA	KH	KB	KU	KT	KJ	-	-
Freeze	<b>12</b>	ZA	ZH	ZB	ZU	ZT	ZJ	-	-
Equipment	<b>13</b>	IA	IR	-	-	-	-	-	-
Equip. Tamper	<b>14</b>	TA	TH	TB	TU	TT	TJ	-	-



## **ECi Software update schedule**